



Read this manual carefully before operating this vehicle. This manual should stay with this vehicle if it is sold.



YAMAHA MOTOR ELECTRONICS CO., LTD.

1450-6, Mori, Mori-machi, Shuchi-gun, Shizuoka-ken, 437-0292 Japan

DECLARATION of CONFORMITY

Company: YAMAHA MOTOR ELECTRONICS CO., LTD.

Address: 1450-6, Mori, Mori-Machi, Shuchi-gun, Shizuoka-Ken, 437-0292 Japan

Hereby declare that the product:

Kind of equipment: IMMOBILIZER

Type-designation: 5SL-00

is in compliance with following norm(s) or documents:

R&TTE Directive(1999/5/EC)

EN300 330-2 v1.3.1(2006-01), EN300 330-2 v1.5.1(2010-02)

EN60950-1:2006/A11:2009

Two or Three-Wheel Motor Vehicles Directive(97/24/EC: Chapter 8, EMC)

Place of issue: Shizuoka, Japan

Date of issue: 1 Aug. 2002

Revisio	Revision record				
No.	Contents	Date			
1	To change contact person and integrate type-designation.	9 Jun. 2005			
$\sqrt{2}$	Version up the norm of EN60950 to EN60950-1	27 Feb. 2006			
3	To change company name	1 Mar. 2007			
4	version up of the following norm: • EN300 330-2 v1.1.1 to EN300 330-2 v1.3.1 and EN300 330-2 v1.5.1 • EN60950-1:2001 to EN60950-1:2006/A11:2009	8 Jul. 2010			

General manager of quality assurance div.

INTRODUCTION

EAU10102

Welcome to the Yamaha world of motorcycling!

As the owner of the YZF-R6, you are benefiting from Yamaha's vast experience and newest technology regarding the design and manufacture of high-quality products, which have earned Yamaha a reputation for dependability.

Please take the time to read this manual thoroughly, so as to enjoy all advantages of your YZF-R6. The Owner's Manual does not only instruct you in how to operate, inspect and maintain your motorcycle, but also in how to safeguard yourself and others from trouble and injury.

In addition, the many tips given in this manual will help keep your motorcycle in the best possible condition. If you have any further questions, do not hesitate to contact your Yamaha dealer.

The Yamaha team wishes you many safe and pleasant rides. So, remember to put safety first!

Yamaha continually seeks advancements in product design and quality. Therefore, while this manual contains the most current product information available at the time of printing, there may be minor discrepancies between your motorcycle and this manual. If there is any question concerning this manual, please consult a Yamaha dealer.

EWA10031

♠ WARNING

Please read this manual carefully and completely before operating this motorcycle.

IMPORTANT MANUAL INFORMATION

EAU10132

Particularly important information is distinguished in this manual by the following notations:

A	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
⚠ WARNING	A WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.
NOTICE	A NOTICE indicates special precautions that must be taken to avoid damage to the vehicle or other property.
TIP	A TIP provides key information to make procedures easier or clearer.

IMPORTANT MANUAL INFORMATION

EAU10200

YZF-R6
OWNER'S MANUAL
©2010 by Yamaha Motor Co., Ltd.
1st edition, May 2010
All rights reserved.
Any reprinting or unauthorized use without the written permission of Yamaha Motor Co., Ltd. is expressly prohibited.
Printed in Japan.

TABLE OF CONTENTS

SAFETY INFORMATION1-1	Luggage strap holders3-27 EXUP system3-28	Checking the engine idling speed	6-19
DESCRIPTION 2-1	Sidestand	Checking the throttle grip free	0 10
Left view2-1	Ignition circuit cut-off system 3-29	play	6-19
Right view2-2	.g 2 2 2 3, 2 2	Valve clearance	
Controls and instruments2-3	FOR YOUR SAFETY -	Tires	
	PRE-OPERATION CHECKS4-1	Cast wheels	
INSTRUMENT AND CONTROL		Adjusting the clutch lever free	•
FUNCTIONS3-1	OPERATION AND IMPORTANT	play	6-23
Immobilizer system3-1	RIDING POINTS 5-1	Checking the brake lever free	
Main switch/steering lock3-2	Starting the engine5-1	play	6-24
Indicator lights and warning	Shifting5-2	Brake light switches	
lights3-4	Tips for reducing fuel	Checking the front and rear brak	
Multi-function meter unit3-8	consumption5-3	pads	
Anti-theft alarm (optional)3-14	Engine break-in5-3	Checking the brake fluid level	
Handlebar switches3-14	Parking5-4	Changing the brake fluid	
Clutch lever3-15	3	Drive chain slack	
Shift pedal3-16	PERIODIC MAINTENANCE AND	Cleaning and lubricating the driv	е
Brake lever3-16	ADJUSTMENT 6-1	chain	
Brake pedal3-17	Owner's tool kit6-2	Checking and lubricating the	
Fuel tank cap3-17	Periodic maintenance chart for the	cables	6-29
Fuel3-18	emission control system6-3	Checking and lubricating the	
Fuel tank breather/overflow	General maintenance and	throttle grip and cable	6-29
hose3-19	lubrication chart6-4	Checking and lubricating the	
Catalytic converters3-19	Removing and installing cowlings	brake and shift pedals	6-30
Seats3-20	and panels6-8	Checking and lubricating the	
Helmet holding cable3-21	Checking the spark plugs6-12	brake and clutch levers	6-30
Rear view mirrors3-22	Engine oil and oil filter cartridge 6-13	Checking and lubricating the	
Adjusting the front fork3-23	Coolant6-16	sidestand	6-31
Adjusting the shock absorber	Air filter element6-19	Lubricating the swingarm	
assembly3-25		pivots	6-31

TABLE OF CONTENTS

Checking the front fork	6-32
Checking the steering	
Checking the wheel bearings	6-33
Battery	
Replacing the fuses	
Replacing a headlight bulb	
Tail/brake light	
Replacing a turn signal light	
bulb	6-37
Replacing the license plate light	
bulb	6-38
Auxiliary light	6-38
Supporting the motorcycle	6-39
Front wheel	
Rear wheel	6-41
Troubleshooting	6-43
Troubleshooting charts	
MOTORCYCLE CARE AND	
STORAGE	7-1
Matte color caution	7-1
Care	7-1
Storage	7-4
SPECIFICATIONS	8-1
CONSUMER INFORMATION	9-1
Identification numbers	Q_1

EAU10287

Safe Riding

Be a Responsible Owner

As the vehicle's owner, you are responsible for the safe and proper operation of your motorcycle.

Motorcycles are single-track vehicles. Their safe use and operation are dependent upon the use of proper riding techniques as well as the expertise of the operator. Every operator should know the following requirements before riding this motorcycle.

He or she should:

- Obtain thorough instructions from a competent source on all aspects of motorcycle operation.
- Observe the warnings and maintenance requirements in this Owner's Manual.
- Obtain qualified training in safe and proper riding techniques.
- Obtain professional technical service as indicated in this Owner's Manual and/or when made necessary by mechanical conditions.

Perform the pre-operation checks each time you use the vehicle to make sure it is in safe operating condition. Failure to inspect or maintain the vehicle properly increases the possibility of an accident or equipment damage. See page 4-1 for a list of pre-operation checks.

- This motorcycle is designed to carry the operator and a passenger.
- The failure of motorists to detect and recognize motorcycles in traffic is the predominating cause of automobile/motorcycle accidents. Many accidents have been caused by an automobile driver who did not see the motorcycle. Making yourself conspicuous appears to be very effective in reducing the chance of this type of accident.

Therefore:

- Wear a brightly colored jacket.
- Use extra caution when you are approaching and passing through intersections, since intersections are the most likely places for motorcycle accidents to occur.

- Ride where other motorists can see you. Avoid riding in another motorist's blind spot.
- Many accidents involve inexperienced operators. In fact, many operators who have been involved in accidents do not even have a current motorcycle license.
 - Make sure that you are qualified and that you only lend your motorcycle to other qualified operators.
 - Know your skills and limits.
 Staying within your limits may help you to avoid an accident.
 - We recommend that you practice riding your motorcycle where there is no traffic until you have become thoroughly familiar with the motorcycle and all of its controls.
- Many accidents have been caused by error of the motorcycle operator. A typical error made by the operator is veering wide on a turn

due to excessive speed or undercornering (insufficient lean angle for the speed).

- Always obey the speed limit and never travel faster than warranted by road and traffic conditions.
- Always signal before turning or changing lanes. Make sure that other motorists can see you.
- The posture of the operator and passenger is important for proper control.
 - The operator should keep both hands on the handlebar and both feet on the operator footrests during operation to maintain control of the motorcycle.
 - The passenger should always hold onto the operator, the seat strap or grab bar, if equipped, with both hands and keep both feet on the passenger footrests. Never carry a passenger unless he or she can firmly place both feet on the passenger footrests.
- Never ride under the influence of alcohol or other drugs.

 This motorcycle is designed for onroad use only. It is not suitable for off-road use.

Protective Apparel

The majority of fatalities from motorcycle accidents are the result of head injuries. The use of a safety helmet is the single most critical factor in the prevention or reduction of head injuries.

- Always wear an approved helmet.
- Wear a face shield or goggles.
 Wind in your unprotected eyes could contribute to an impairment of vision that could delay seeing a hazard.
- The use of a jacket, heavy boots, trousers, gloves, etc., is effective in preventing or reducing abrasions or lacerations.
- Never wear loose-fitting clothes, otherwise they could catch on the control levers, footrests, or wheels and cause injury or an accident.
- Always wear protective clothing that covers your legs, ankles, and feet. The engine or exhaust system become very hot during or after operation and can cause burns.

 A passenger should also observe the above precautions.

Avoid Carbon Monoxide Poisoning

All engine exhaust contains carbon monoxide, a deadly gas. Breathing carbon monoxide can cause headaches, dizziness, drowsiness, nausea, confusion, and eventually death.

Carbon Monoxide is a colorless, odorless, tasteless gas which may be present even if you do not see or smell any engine exhaust. Deadly levels of carbon monoxide can collect rapidly and you can quickly be overcome and unable to save yourself. Also, deadly levels of carbon monoxide can linger for hours or days in enclosed or poorly ventilated areas. If you experience any symptoms of carbon monoxide poisoning, leave the area immediately, get fresh air, and SEEK MEDICAL TREAT-MENT.

 Do not run engine indoors. Even if you try to ventilate engine exhaust with fans or open windows and doors, carbon monoxide can rapidly reach dangerous levels.

- Do not run engine in poorly ventilated or partially enclosed areas such as barns, garages, or carports.
- Do not run engine outdoors where engine exhaust can be drawn into a building through openings such as windows and doors.

Loading

Adding accessories or cargo to your motorcycle can adversely affect stability and handling if the weight distribution of the motorcycle is changed. To avoid the possibility of an accident, use extreme caution when adding cargo or accessories to your motorcycle. Use extra care when riding a motorcycle that has added cargo or accessories. Here, along with the information about accessories below, are some general guidelines to follow if loading cargo to your motorcycle:

The total weight of the operator, passenger, accessories and cargo must not exceed the maximum load limit. Operation of an overloaded vehicle could cause an accident.

Maximum load: 186 kg (410 lb)

When loading within this weight limit, keep the following in mind:

- Cargo and accessory weight should be kept as low and close to the motorcycle as possible. Securely pack your heaviest items as close to the center of the vehicle as possible and make sure to distribute the weight as evenly as possible on both sides of the motorcycle to minimize imbalance or instability.
- Shifting weights can create a sudden imbalance. Make sure that accessories and cargo are securely attached to the motorcycle before riding. Check accessory mounts and cargo restraints frequently.
 - Properly adjust the suspension for your load (suspension-adjustable models only), and check the condition and pressure of your tires.
 - Never attach any large or heavy items to the handlebar, front fork, or front fender. These

- items, including such cargo as sleeping bags, duffel bags, or tents, can create unstable handling or a slow steering response.
- This vehicle is not designed to pull a trailer or to be attached to a sidecar.

Genuine Yamaha Accessories

Choosing accessories for your vehicle is an important decision. Genuine Yamaha accessories, which are available only from a Yamaha dealer, have been designed, tested, and approved by Yamaha for use on your vehicle.

Many companies with no connection to Yamaha manufacture parts and accessories or offer other modifications for Yamaha vehicles. Yamaha is not in a position to test the products that these aftermarket companies produce. Therefore, Yamaha can neither endorse nor recommend the use of accessories not sold by Yamaha or modifications not specifically recommended by Yamaha, even if sold and installed by a Yamaha dealer.

Aftermarket Parts, Accessories, and Modifications

While you may find aftermarket products similar in design and quality to genuine Yamaha accessories, recognize that some aftermarket accessories or modifications are not suitable because of potential safety hazards to you or others. Installing aftermarket products or having other modifications performed to your vehicle that change any of the vehicle's design or operation characteristics can put you and others at greater risk of serious injury or death. You are responsible for injuries related to changes in the vehicle.

Keep the following guidelines in mind, as well as those provided under "Loading" when mounting accessories.

 Never install accessories or carry cargo that would impair the performance of your motorcycle. Carefully inspect the accessory before using it to make sure that it does not in any way reduce ground clearance or cornering clearance, limit suspension travel, steering travel or control operation, or obscure lights or reflectors.

- Accessories fitted to the handlebar or the front fork area can create instability due to improper weight distribution or aerodynamic changes. If accessories are added to the handlebar or front fork area, they must be as lightweight as possible and should be kept to a minimum.
- Bulky or large accessories may seriously affect the stability of the motorcycle due to aerodynamic effects. Wind may attempt to lift the motorcycle, or the motorcycle may become unstable in cross winds. These accessories may also cause instability when passing or being passed by large vehicles.
- Certain accessories can displace the operator from his or her normal riding position. This improper position limits the freedom of movement of the opera-

- tor and may limit control ability, therefore, such accessories are not recommended.
- Use caution when adding electrical accessories. If electrical accessories exceed the capacity of the motorcycle's electrical system, an electric failure could result, which could cause a dangerous loss of lights or engine power.

Aftermarket Tires and Rims

The tires and rims that came with your motorcycle were designed to match the performance capabilities and to provide the best combination of handling, braking, and comfort. Other tires, rims, sizes, and combinations may not be appropriate. Refer to page 6-20 for tire specifications and more information on replacing your tires.

Transporting the Motorcycle


Be sure to observe following instructions before transporting the motorcycle in another vehicle.

• Remove all loose items from the motorcycle.

- Check that the fuel cock (if equipped) is in the "OFF" position and that there are no fuel leaks.
- Point the front wheel straight ahead on the trailer or in the truck bed, and choke it in a rail to prevent movement.
- Shift the transmission in gear (for models with a manual transmission).
- Secure the motorcycle with tiedowns or suitable straps that are attached to solid parts of the motorcycle, such as the frame or upper front fork triple clamp (and not, for example, to rubber-mounted handlebars or turn signals, or parts that could break). Choose the location for the straps carefully so the straps will not rub against painted surfaces during transport.
- The suspension should be compressed somewhat by the tiedowns, if possible, so that the motorcycle will not bounce excessively during transport.

Left view






- 1. Fuse box 2 (page 6-34)
- 2. Front fork spring preload adjusting bolt (page 3-23)
- 3. Front fork rebound damping force adjusting screw (page 3-23)
- 4. Shock absorber assembly spring preload adjusting ring (page 3-25)
- Shock absorber assembly compression damping force adjusting bolt (for fast compression damping) (page 3-25)
- 6. Shock absorber assembly compression damping force adjusting bolt (for slow compression damping) (page 3-25)
- 7. Owner's tool kit (page 6-2)

- 8. Shock absorber assembly rebound damping force adjusting screw (page 3-25)
- 9. Shift pedal (page 3-16)
- 10. Engine oil filter cartridge (page 6-13)
- 11.Engine oil drain bolt (page 6-13)
- 12. Front fork compression damping force adjusting bolt (for fast compression damping) (page 3-23)
- 13.Front fork compression damping force adjusting bolt (for slow compression damping) (page 3-23)

Right view



- 1. Luggage strap holder (page 3-27)
- 2. Helmet cable holder (page 3-21)
- 3. Fuse box 1 (page 6-34)
- 4. Main fuse (page 6-34)
- 5. Fuel injection system fuse (page 6-34)
- 6. Battery (page 6-33)
- 7. Air filter element (page 6-19)
- 8. Coolant reservoir (page 6-16)


- 9. Radiator cap (page 6-16)
- 10.Engine oil filler cap (page 6-13)

EAU10420

- 11.Coolant drain bolt (page 6-17)
- 12. Engine oil dipstick (page 6-13)
- 13.Brake pedal (page 3-17)
- 14.Rear brake light switch (page 6-24)
- 15.Rear brake fluid reservoir (page 6-25)

Controls and instruments






- 1. Clutch lever (page 3-15)
- 2. Left handlebar switches (page 3-14)
- 3. Main switch/steering lock (page 3-2)
- 4. Multi-function meter unit (page 3-8)
- 5. Front brake fluid reservoir (page 6-25)
- 6. Right handlebar switches (page 3-14)
- 7. Brake lever (page 3-16)
- 8. Throttle grip (page 6-19)

EAU10977

Immobilizer system



- 1. Code re-registering key (red bow)
- 2. Standard keys (black bow)

This vehicle is equipped with an immobilizer system to help prevent theft by re-registering codes in the standard keys. This system consists of the following:

- a code re-registering key (with a red bow)
- two standard keys (with a black bow) that can be re-registered with new codes
- a transponder (which is installed in the code re-registering key)
- an immobilizer unit
- an ECU

 an immobilizer system indicator light (See page 3-7.)

The key with the red bow is used to register codes in each standard key. Since re-registering is a difficult process, take the vehicle along with all three keys to a Yamaha dealer to have them re-registered. Do not use the key with the red bow for driving. It should only be used for re-registering the standard keys. Always use a standard key for driving.

ECA11821

NOTICE

• DO NOT LOSE THE CODE RE-REGISTERING KEY! CONTACT YOUR DEALER IMMEDIATELY IF IT IS LOST! If the code re-registering key is lost, registering new codes in the standard keys is impossible. The standard keys can still be used to start the vehicle, however if code reregistering is required (i.e., if a new standard key is made or all keys are lost) the entire immobilizer system must be replaced. Therefore, it is highly recommended to use either standard key and keep the code re-registering key in a safe place.

- Do not submerse any key in water.
- Do not expose any key to excessively high temperatures.
- Do not place any key close to magnets (this includes, but not limited to, products such as speakers, etc.).
- Do not place items that transmit electrical signals close to any key.
- Do not place heavy items on any key.
- Do not grind any key or alter its shape.
- Do not disassemble the plastic part of any key.
- Do not put two keys of any immobilizer system on the same key ring.
- Keep the standard keys as well as keys of other immobilizer systems away from this vehicle's code re-registering key.

 Keep other immobilizer system keys away from the main switch as they may cause signal interference.

Main switch/steering lock



The main switch/steering lock controls the ignition and lighting systems, and is used to lock the steering. The various positions are described below.

TIP

Be sure to use the standard key (black bow) for regular use of the vehicle. To minimize the risk of losing the code reregistering key (red bow), keep it in a safe place and only use it for code reregistering.

EAU10472

ON

All electrical circuits are supplied with power; the meter lighting, taillight, license plate light and auxiliary light come on, and the engine can be started. The key cannot be removed.

TIP ____

The headlight comes on automatically when the engine is started and stays on until the key is turned to "OFF", even if the engine stalls.

EAU10661

EAU38530

OFF

All electrical systems are off. The key can be removed.

EWA10061

WARNING


Never turn the key to "OFF" or "LOCK" while the vehicle is moving. Otherwise the electrical systems will be switched off, which may result in loss of control or an accident.

EAU10683

LOCK


The steering is locked, and all electrical systems are off. The key can be removed.

To lock the steering



- 1. Push.
- 2. Turn.
 - 1. Turn the handlebars all the way to the left.
- 2. Push the key in from the "OFF" position, and then turn it to "LOCK" while still pushing it.
- 3. Remove the key.

To unlock the steering



- 1. Push.
- 2. Turn.

Push the key in, and then turn it to "OFF" while still pushing it.

EAU34341

p**∈ (Parking)**

The steering is locked, and the taillight, license plate light and auxiliary light are on. The hazard lights and turn signal lights can be turned on, but all other electrical systems are off. The key can be removed.

The steering must be locked before the key can be turned to " $p \le$ ".


ECA11020

NOTICE

Do not use the parking position for an extended length of time, otherwise the battery may discharge.

3

FAU49391 Indicator lights and warning lights



- 1. Left turn signal indicator light "<□"
- 2. Neutral indicator light " N "
- 3. High beam indicator light "≣∩"
- 5. Fuel level warning light "" "
- 6. Oil level warning light " 5 "
- 7. Coolant temperature warning light " . L. "
- 8. Shift timing indicator light
- 9. Engine trouble warning light " เก็ว "
- 10.Immobilizer system indicator light

Turn signal indicator lights "<> " and "⇔"

The corresponding indicator light flashes when the turn signal switch is pushed to the left or right.

Neutral indicator light "N"

This indicator light comes on when the transmission is in the neutral position.

High beam indicator light "≣⊖" This indicator light comes on when the high beam of the headlight is switched

EAU11254

EAU11060

Oil level warning light " "

This warning light comes on if the engine oil level is low.

The electrical circuit of the warning light can be checked by turning the key to "ON". The warning light should come on for a few seconds, and then go off. If the warning light does not come on initially when the key is turned to "ON", or if the warning light remains on, have a Yamaha dealer check the electrical circuit.

TIP

on.

 Even if the oil level is sufficient, the warning light may flicker when riding on a slope or during sudden acceleration or deceleration, but this is not a malfunction.

This model is also equipped with a self-diagnosis device for the oil level detection circuit. If a problem is detected in the oil level detection. circuit, the following cycle will be repeated until the malfunction is corrected: The oil level warning light will flash ten times, then go off for 2.5 seconds. If this occurs, have a Yamaha dealer check the vehicle.

EAU11365

Fuel level warning light "■"

This warning light comes on when the fuel level drops below approximately 3.5 L (0.92 US gal, 0.77 Imp.gal). When this occurs, refuel as soon as possible. The electrical circuit of the warning light can be checked by turning the key to "ON". The warning light should come on for a few seconds, and then go off. If the warning light does not come on initially when the key is turned to "ON", or if the warning light remains on, have a Yamaha dealer check the electrical circuit.

TIP_

This model is also equipped with a self-diagnosis device for the fuel level detection circuit. If a problem is detected in the fuel level detection circuit, the following cycle will be repeated until the malfunction is corrected: The fuel level warning light will flash eight times, and then go off for 3.0 seconds. If this occurs, have a Yamaha dealer check the vehicle.

EAU11428

Coolant temperature warning light " ... "

This warning light comes on if the engine overheats. If this occurs, stop the engine immediately and allow the engine to cool.

The electrical circuit of the warning light can be checked by turning the key to "ON". The warning light should come on for a few seconds, and then go off. If the warning light does not come on initially when the key is turned to "ON", or if the warning light remains on, have a Yamaha dealer check the electrical circuit.

ECA10021

NOTICE

Do not continue to operate the engine if it is overheating.

TIP_

- For radiator-fan-equipped vehicles, the radiator fan(s) automatically switch on or off according to the coolant temperature in the radiator.
- If the engine overheats, see page 6-45 for further instructions.

Display		Conditions	What to do
Under 39 °C (Under 103 °F)	1000 PARA LOC DID	Message "Lo" is displayed.	OK. Go ahead with riding.
40–116 °C (104–242 °F)		Coolant temperature is displayed.	OK. Go ahead with riding.
117–134 °C (243–274 °F)		Coolant temperature flashes. Warning light comes on.	Stop the vehicle and allow it to idle until the coolant temperature goes down. If the temperature does not go down, stop the engine. (See page 6-45.)
Above 135 °C (Above 275 °F)	1000 1000 1000 1000 1000 1000 1000 100	Message "HI" flashes. Warning light comes on.	Stop the engine and allow it to cool. (See page 6-45.)

EAU11574

Engine trouble warning light " 📇 "

This warning light comes on if a problem is detected in the electrical circuit monitoring the engine. If this occurs, have a Yamaha dealer check the selfdiagnosis system. (See page 3-11 for an explanation of the self-diagnosis device.)

The electrical circuit of the warning light can be checked by turning the key to "ON". The warning light should come on for a few seconds, and then go off. If the warning light does not come on initially when the key is turned to "ON", or if the warning light remains on, have a Yamaha dealer check the electrical circuit.

Shift timing indicator light

This indicator light can be set to come on and go off at the desired engine speeds and is used to inform the rider when it is time to shift to the next higher gear.

The electrical circuit of the indicator light can be checked by turning the key to "ON". The indicator light should come on for a few seconds, and then go off.

If the indicator light does not come on initially when the key is turned to "ON", or if the indicator light remains on, have a Yamaha dealer check the electrical circuit. (See page 3-11 for a detailed explanation of the function of this indicator light and on how to set it.)

EAU38624

Immobilizer system indicator light

The electrical circuit of the indicator light can be checked by turning the key to "ON". The indicator light should come on for a few seconds, and then go off.


If the indicator light does not come on initially when the key is turned to "ON", or if the indicator light remains on, have a Yamaha dealer check the electrical circuit.

When the key is turned to "OFF" and 30 seconds have passed, the indicator light will start flashing indicating the immobilizer system is enabled. After 24

hours have passed, the indicator light will stop flashing, however the immobilizer system is still enabled.

The self-diagnosis device also detects problems in the immobilizer system circuits. (See page 3-11 for an explanation of the self-diagnosis device.)

Multi-function meter unit



- 1. Speedometer
- 2. Clock
- 3. Tachometer
- 4. Coolant temperature display/air intake temperature display
- 5. Odometer/tripmeter/fuel reserve tripmeter/stopwatch
- 6. Shift timing indicator light
- 7. "RESET" button
- 8. "SELECT" button

EWA12422

EAU39047

WARNING

Be sure to stop the vehicle before making any setting changes to the multi-function meter unit. Changing settings while riding can distract the operator and increase the risk of an accident.


The multi-function meter unit is equipped with the following:

- a speedometer
- a tachometer
- an odometer
- two tripmeters (which show the distance traveled since they were last set to zero)
- a fuel reserve tripmeter (which shows the distance traveled since the fuel level warning light came on)
- a stopwatch
- a clock
- a coolant temperature display
- an air intake temperature display
- a self-diagnosis device
- a display brightness and shift timing indicator light control mode

TIP.

 Be sure to turn the key to "ON" before using the "SELECT" and "RE-SET" buttons, except for setting the display brightness and shift timing indicator light control mode. For the U.K. only: To switch the speedometer and odometer/tripmeter displays between kilometers and miles, press the "SELECT" button for at least one second.

Tachometer



- 1. Tachometer
- 2. Tachometer red zone

The electric tachometer allows the rider to monitor the engine speed and keep it within the ideal power range.

When the key is turned to "ON", the tachometer needle will sweep once across the r/min range and then return to zero r/min in order to test the electrical circuit.


ECA10031

NOTICE

Do not operate the engine in the tachometer red zone.

Red zone: 16500 r/min and above

Clock




1. Clock

To set the clock

- 1. Turn the key to "ON".
- 2. Push the "SELECT" button and "RESET" button together for at least two seconds.
- When the hour digits start flashing, push the "RESET" button to set the hours.
- 4. Push the "SELECT" button, and the minute digits will start flashing.

- 5. Push the "RESET" button to set the minutes.
- 6. Push the "SELECT" button and then release it to start the clock.

Odometer, tripmeter, and stopwatch modes



Odometer/tripmeter/fuel reserve tripmeter/stopwatch

Push the "SELECT" button to switch the display between the odometer mode "ODO", the tripmeter modes "TRIP A" and "TRIP B" and the stopwatch mode in the following order:

TRIP A \rightarrow TRIP B \rightarrow ODO \rightarrow Stopwatch \rightarrow TRIP A

If the fuel level warning light comes on (see page 3-4), the odometer display will automatically change to the fuel reserve tripmeter mode "F-TRIP" and start counting the distance traveled from that point. In that case, push the "SELECT" button to switch the display between the various tripmeter, odometer, and stopwatch modes in the following order:

F-TRIP \rightarrow Stopwatch \rightarrow TRIP A \rightarrow TRIP B \rightarrow ODO \rightarrow F-TRIP

To reset a tripmeter, select it by pushing the "SELECT" button, and then push the "RESET" button for at least one second. If you do not reset the fuel reserve tripmeter manually, it will reset itself automatically and the display will return to the prior mode after refueling and traveling 5 km (3 mi).

Stopwatch mode

To change the display to the stopwatch mode, select it by pushing the "SE-LECT" button. (The stopwatch digits will start flashing.) Release the "SE-LECT" button, and then push it again for a few seconds until the stopwatch digits stop flashing.

Standard measurement

- 1. Push the "RESET" button to start the stopwatch.
- 2. Push the "SELECT" button to stop the stopwatch.
- 3. Push the "SELECT" button again to reset the stopwatch.


Split-time measurement

- 1. Push the "RESET" button to start the stopwatch.
- 2. Push the "RESET" button or start switch "(s)" to measure split-times. (The colon ":" will start flashing.)
- Push the "RESET" button or start switch "(§)" to display the final splittime or push the "SELECT" button to stop the stopwatch and display total elapsed time.
- 4. Push the "SELECT" button to reset the stopwatch.

TIP

To change the display back to the prior mode, push the "SELECT" button for a few seconds until the stopwatch digits flash.

Coolant temperature display



1. Coolant temperature display

The coolant temperature display indicates the temperature of the coolant.


TIP _____

When the coolant temperature display is selected, "C" is displayed for one second, and then the coolant temperature is displayed.

NOTICE

Do not continue to operate the engine if it is overheating.

Air intake temperature display



1. Air intake temperature display

The air intake temperature display indicates the temperature of the air drawn into the air intake duct. Push the "RESET" button to switch the coolant temperature display to the air intake temperature display.


TIP

ECA10021

- Even if the air intake temperature is set to be displayed, the coolant temperature warning light comes on if the engine overheats.
- When the key is turned to "ON", the coolant temperature is automatically displayed, even if the air intake temperature was displayed prior to turning the key to "OFF".

 When the air intake temperature display is selected, "A" is displayed before the temperature.

Self-diagnosis device



1. Error code display

This model is equipped with a self-diagnosis device for various electrical circuits.

If a problem is detected in any of those circuits, the engine trouble warning light will come on and the right display will indicate an error code.

If the right display indicates any error codes, note the code number, and then have a Yamaha dealer check the vehicle.

The self-diagnosis device also detects problems in the immobilizer system circuits.

If a problem is detected in the immobilizer system circuits, the immobilizer system indicator light will flash and the right display will indicate an error code.

TIP_

If the right display indicates error code 52, this could be caused by transponder interference. If this error code appears, try the following.

1. Use the code re-registering key to start the engine.

TIP

Make sure there are no other immobilizer keys close to the main switch, and do not keep more than one immobilizer key on the same key ring! Immobilizer system keys may cause signal interference, which may prevent the engine from starting.


If the engine starts, turn it off and try starting the engine with the standard keys. If one or both of the standard keys do not start the engine, take the vehicle, the code re-registering key and both standard keys to a Yamaha dealer and have the standard keys re-registered.

ECA11590

NOTICE

If the display indicates an error code, the vehicle should be checked as soon as possible in order to avoid engine damage.

Display brightness and shift timing indicator light control mode



- 1. Shift timing indicator light activation range
- 2. Brightness adjustable displays
- 3. Brightness level
- 4. Shift timing indicator light

This mode cycles through five control functions, allowing you to make the following settings in the order listed below.

- Display brightness:
 - This function allows you to adjust the brightness of the displays and tachometer to suit the outside lighting conditions.
- Shift timing indicator light activity: This function allows you to choose whether or not the indicator light should be activated and whether it should flash or stay on when activated.
- Shift timing indicator light activation:
 - This function allows you to select the engine speed at which the indicator light will be activated.
- Shift timing indicator light deactivation:

This function allows you to select the engine speed at which the indicator light will be deactivated. Shift timing indicator light brightness:

This function allows you to adjust the brightness of the indicator light to suit your preference.

TIP_

In this mode, the right display shows the current setting for each function (except the shift timing indicator light activity function).

To adjust the brightness of the multifunction meter displays and tachometer

- 1. Turn the key to "OFF".
- 2. Push and hold the "SELECT" button.
- 3. Turn the key to "ON", and then release the "SELECT" button after five seconds.
- 4. Push the "RESET" button to select the desired brightness level.
- 5. Push the "SELECT" button to confirm the selected brightness level.

 The control mode changes to the shift timing indicator light activity function.

To set the shift timing indicator light activity function

- Push the "RESET" button to select one of the following indicator light activity settings:
 - The indicator light will stay on when activated. (This setting is selected when the indicator light stays on.)
 - The indicator light will flash when activated. (This setting is selected when the indicator light flashes four times per second.)
 - The indicator light is deactivated; in other words, it will not come on or flash. (This setting is selected when the indicator light flashes once every two seconds.)
- Push the "SELECT" button to confirm the selected indicator light activity. The control mode changes to the shift timing indicator light activation function.

To set the shift timing indicator light activation function

TIP _____

The shift timing indicator light activation function can be set between 10000 r/min and 18000 r/min. From 10000 r/min to 13000 r/min, the indicator light can be set in increments of 500 r/min. From 13000 r/min to 18000 r/min, the indicator light can be set in increments of 200 r/min.

- Push the "RESET" button to select the desired engine speed for activating the indicator light.
- Push the "SELECT" button to confirm the selected engine speed.
 The control mode changes to the shift timing indicator light deactivation function.

To set the shift timing indicator light deactivation function

TIP _____

 The shift timing indicator light deactivation function can be set between 10000 r/min and 18000 r/min. From 10000 r/min to 13000

- r/min, the indicator light can be set in increments of 500 r/min. From 13000 r/min to 18000 r/min, the indicator light can be set in increments of 200 r/min.
- Be sure to set the deactivation function to a higher engine speed than for the activation function, otherwise the shift timing indicator light will remain deactivated.
- 1. Push the "RESET" button to select the desired engine speed for deactivating the indicator light.
- Push the "SELECT" button to confirm the selected engine speed.
 The control mode changes to the shift timing indicator light brightness function.

To adjust the shift timing indicator light brightness

 Push the "RESET" button to select the desired indicator light brightness level. Push the "SELECT" button to confirm the selected indicator light brightness level. The right display will return to the odometer or tripmeter mode.


Anti-theft alarm (optional)

This model can be equipped with an optional anti-theft alarm by a Yamaha dealer. Contact a Yamaha dealer for more information.

Handlebar switches

Left


EAU12331



- 1. Pass switch " ≣⊜"
- 2. Dimmer switch "≣O/≣O"
- 3. Turn signal switch "⟨¬/ ¬⟩"
- 4. Horn switch "
- 5. Hazard switch " A "

EAU12348

Right



- 1. Engine stop switch "∩/⊠"
- 2. Start switch "(≶)"

EAU12350

Pass switch "≣⊘"

Press this switch to flash the headlight.

Dimmer switch "≣⊜/≣⊜"

Set this switch to " \equiv " for the high beam and to " \approx " for the low beam.

Turn signal switch "⟨¬/⟨¬⟩"

To signal a right-hand turn, push this switch to "⇔". To signal a left-hand turn, push this switch to "⇐". When released, the switch returns to the center

EAU12400

EAU12460

3-14

position. To cancel the turn signal lights, push the switch in after it has returned to the center position.

EAU12500

Horn switch " ► "

Press this switch to sound the horn.

Engine stop switch "∩/⊠"

Set this switch to "\(\cap\)" before starting the engine. Set this switch to "\(\omega\)" to stop the engine in case of an emergency, such as when the vehicle overturns or when the throttle cable is stuck.

EAU12711

Start switch "(§)"

Push this switch to crank the engine with the starter. See page 5-1 for starting instructions prior to starting the engine.

EAU4170

The engine trouble warning light will come on when the key is turned to "ON" and the start switch is pushed, but this does not indicate a malfunction.

Hazard switch " △ "

With the key in the "ON" or "p∈" position, use this switch to turn on the hazard lights (simultaneous flashing of all turn signal lights).

The hazard lights are used in case of an emergency or to warn other drivers when your vehicle is stopped where it might be a traffic hazard.


ECA10061

EAU12733

NOTICE

Do not use the hazard lights for an extended length of time with the engine not running, otherwise the battery may discharge.

Clutch lever




EAU12820

1. Clutch lever

The clutch lever is located at the left handlebar grip. To disengage the clutch, pull the lever toward the handlebar grip. To engage the clutch, release the lever. The lever should be pulled rapidly and released slowly for smooth clutch operation.

The clutch lever is equipped with a clutch switch, which is part of the ignition circuit cut-off system. (See page 3-29.)

Shift pedal




1. Shift pedal

The shift pedal is located on the left side of the motorcycle and is used in combination with the clutch lever when shifting the gears of the 6-speed constant-mesh transmission equipped on this motorcycle.

Brake lever

EAU12871



- 1. Brake lever
- Distance between brake lever and handlebar grip
- 3. " /\ " mark
- 4. Brake lever position adjusting knob


The brake lever is located at the right handlebar grip. To apply the front brake, pull the lever toward the handlebar grip.

The brake lever is equipped with a brake lever position adjusting knob. To adjust the distance between the brake lever and the handlebar grip, turn the adjusting knob while holding the lever pushed away from the handlebar grip. When the desired position is obtained,

be sure to set it by aligning a groove on the adjusting knob with the " \triangle " mark on the brake lever.

EAU12941


Brake pedal



1. Brake pedal

The brake pedal is on the right side of the motorcycle. To apply the rear brake, press down on the brake pedal.

Fuel tank cap



- 1. Fuel tank cap lock cover
- 2. Unlock.

To open the fuel tank cap

Open the fuel tank cap lock cover, insert the key into the lock, and then turn it 1/4 turn clockwise. The lock will be released and the fuel tank cap can be opened.

To close the fuel tank cap

- 1. Push the fuel tank cap into position with the key inserted in the lock.
- 2. Turn the key counterclockwise to the original position, remove it, and then close the lock cover.

TIP

EAU13074

The fuel tank cap cannot be closed unless the key is in the lock. In addition, the key cannot be removed if the cap is not properly closed and locked.

EWA11091

WARNING

Make sure that the fuel tank cap is properly closed after filling fuel. Leaking fuel is a fire hazard.

EAU13221

Fuel


Make sure there is sufficient gasoline in the tank.

EWA10881

WARNING

Gasoline and gasoline vapors are extremely flammable. To avoid fires and explosions and to reduce the risk of injury when refueling, follow these instructions.

- Before refueling, turn off the engine and be sure that no one is sitting on the vehicle. Never refuel while smoking, or while in the vicinity of sparks, open flames, or other sources of ignition such as the pilot lights of water heaters and clothes dryers.
- Do not overfill the fuel tank. When refueling, be sure to insert the pump nozzle into the fuel tank filler hole. Stop filling when the fuel reaches the bottom of the filler tube. Because fuel expands when it heats up, heat from the engine or the sun can cause fuel to spill out of the fuel tank.



- 1. Fuel tank filler tube
- 2. Maximum fuel level
 - 3. Wipe up any spilled fuel immediately. NOTICE: Immediately wipe off spilled fuel with a clean, dry, soft cloth, since fuel may deteriorate painted surfaces or plastic parts. [ECA10071]
 - 4. Be sure to securely close the fuel tank cap.

EWA15151

WARNING

Gasoline is poisonous and can cause injury or death. Handle gasoline with care. Never siphon gasoline by mouth. If you should swallow some gasoline or inhale a lot of gasoline vapor, or get some gasoline in your eyes, see your doctor immedi-

ately. If gasoline spills on your skin, wash with soap and water. If gasoline spills on your clothing, change your clothes.

EAU13390

Recommended fuel:

PREMIUM UNLEADED GASOLINE ONLY

Fuel tank capacity:

17.3 L (4.57 US gal, 3.81 Imp.gal) Fuel reserve amount (when the fuel level warning light comes on):

3.5 L (0.92 US gal, 0.77 Imp.gal)

ECA11400


NOTICE

Use only unleaded gasoline. The use of leaded gasoline will cause severe damage to internal engine parts, such as the valves and piston rings, as well as to the exhaust system.

Your Yamaha engine has been designed to use premium unleaded gasoline with a research octane number of 95 or higher. If knocking (or pinging) occurs, use a gasoline of a different

brand. Use of unleaded fuel will extend spark plug life and reduce maintenance costs.

Fuel tank breather/overflow hose



1. Fuel tank breather/overflow hose

Before operating the motorcycle:

- Check the fuel tank breather/overflow hose connection.
- Check the fuel tank breather/overflow hose for cracks or damage, and replace it if damaged.
- Make sure that the end of the fuel tank breather/overflow hose is not blocked, and clean it if necessary.

EAU13445

Catalytic converters

This vehicle is equipped with catalytic converters in the exhaust system.

EWA10862

WARNING

FAU39451

The exhaust system is hot after operation. To prevent a fire hazard or burns:

- Do not park the vehicle near possible fire hazards such as grass or other materials that easily burn.
- Park the vehicle in a place where pedestrians or children are not likely to touch the hot exhaust system.
- Make sure that the exhaust system has cooled down before doing any maintenance work.
- Do not allow the engine to idle more than a few minutes. Long idling can cause a build-up of heat.

EAU39032

NOTICE

Use only unleaded gasoline. The use of leaded gasoline will cause unrepairable damage to the catalytic converter.


Seats

ECA10701

Rider seat

To remove the rider seat


Pull back the rear of the rider seat as shown, remove the bolts, and then pull the seat off.



1. Bolt

To install the rider seat

Insert the projection on the front of the rider seat into the seat holder as shown, place the seat in the original position, and then install the bolts.




- 1. Projection
- 2. Seat holder

Passenger seat

To remove the passenger seat


1. Insert the key into the passenger seat lock, and then turn it clockwise.



- 1. Passenger seat lock
- 2. Unlock.
- 2. While holding the key in that position, lift the front of the passenger seat and pull it forward.

To install the passenger seat

 Insert the projections on the passenger seat into the seat holders as shown, and then push the front of the seat down to lock it in place.




- 1. Projection
- 2. Seat holder
 - 2. Remove the key.

TIP.

Make sure that the seats are properly secured before riding.

Helmet holding cable

EAU39073



- 1. Helmet holding cable
- 2. Helmet cable holder
- 3. Middle snap hook

A helmet holding cable is provided in the owner's tool kit to secure two helmets to the helmet cable holder equipped on the bottom of the passenger seat.


To secure a helmet with the helmet holding cable

- 1. Remove the passenger seat. (See page 3-20.)
- 2. Clip the middle snap hook of the cable onto the cable holder.


EAU39671

INSTRUMENT AND CONTROL FUNCTIONS

Pass one of the other snap hooks of the cable through the helmet strap buckle, and then clip the snap hook onto the cable holder as shown.



- 1. Snap hook
- 2. Helmet holding cable
- 3. Helmet
 - 4. Install the passenger seat. WARNING! Never ride with a helmet attached to a helmet holding cable, since the helmet may hit objects, causing loss of control and possibly an accident. [EWA14331]




- 1. Helmet holding cable
- 2. Helmet

To release a helmet from the helmet holding cable

- 1. Remove the passenger seat.
- Unfasten the snap hooks from the cable holder, and then remove the cable from the helmet strap buckle.
- 3. Install the passenger seat.

Rear view mirrors

The rear view mirrors of this vehicle can be folded forward or backward for parking in narrow spaces. Fold the mirrors back to their original position before riding.



- 1. Riding position
- 2. Parking position

EWA14371

WARNING

Be sure to fold the rear view mirrors back to their original position before riding.

Adjusting the front fork

EAU38944

EWA10180

WARNING

Always adjust both fork legs equally, otherwise poor handling and loss of stability may result.

This front fork is equipped with spring preload adjusting bolts, rebound damping force adjusting screws, compression damping force adjusting bolts (for fast compression damping) and compression damping force adjusting bolts (for slow compression damping).


ECA10101

NOTICE

To avoid damaging the mechanism, do not attempt to turn beyond the maximum or minimum settings.


Spring preload

To increase the spring preload and thereby harden the suspension, turn the adjusting bolt on each fork leg in direction (a). To decrease the spring preload and thereby soften the suspension, turn the adjusting bolt on each fork leg in direction (b).



1. Spring preload adjusting bolt

Align the appropriate groove on the adjusting mechanism with the top of the front fork collar.



- 1. Current setting
- 2. Front fork collar

Spring preload setting:

Minimum (soft):

0

Standard:


2

Maximum (hard):

5

Rebound damping force

To increase the rebound damping force and thereby harden the rebound damping, turn the adjusting screw on each fork leg in direction (a). To decrease the rebound damping force and thereby soften the rebound damping, turn the adjusting screw on each fork leg in direction (b).



1. Rebound damping force adjusting screw

Rebound damping setting:

Minimum (soft):

25 click(s) in direction (b)*

Standard:

20 click(s) in direction (b)* Maximum (hard):


1 click(s) in direction (b)*

* With the adjusting screw fully turned in direction (a)

Compression damping force

To adjust the compression damping force (for fast compression damping)

To increase the compression damping force and thereby harden the compression damping, turn the adjusting bolt on each fork leg in direction (a). To decrease the compression damping force and thereby soften the compression damping, turn the adjusting bolt on each fork leg in direction (b).



 Compression damping force adjusting bolt (for fast compression damping)

Compression damping setting (for fast compression damping):

Minimum (soft):

4 turn(s) in direction (b)* Standard:


2 turn(s) in direction (b)* Maximum (hard):

0 turn(s) in direction (b)*

* With the adjusting bolt fully turned in direction (a)

To adjust the compression damping force (for slow compression damping)

To increase the compression damping force and thereby harden the compression damping, turn the adjusting bolt on each fork leg in direction (a). To decrease the compression damping force and thereby soften the compression damping, turn the adjusting bolt on each fork leg in direction (b).



 Compression damping force adjusting bolt (for slow compression damping)

Compression damping setting (for slow compression damping):

Minimum (soft):

20 click(s) in direction (b)* Standard:

15 click(s) in direction (b)* Maximum (hard):

1 click(s) in direction (b)*

* With the adjusting bolt fully turned in direction (a)

TIP

Although the total number of clicks of a damping force adjusting mechanism may not exactly match the above spec-

ifications due to small differences in production, the actual number of clicks always represents the entire adjusting range. To obtain a precise adjustment, it would be advisable to check the number of clicks of each damping force adjusting mechanism and to modify the specifications as necessary.

Adjusting the shock absorber assembly

This shock absorber assembly is equipped with a spring preload adjusting ring, a rebound damping force adjusting screw, a compression damping force adjusting bolt (for fast compression damping) and a compression damping force adjusting bolt (for slow compression damping).

ECA10101


NOTICE

To avoid damaging the mechanism, do not attempt to turn beyond the maximum or minimum settings.

Spring preload

To increase the spring preload and thereby harden the suspension, turn the adjusting ring in direction (a). To decrease the spring preload and thereby soften the suspension, turn the adjusting ring in direction (b).

 Align the appropriate notch in the adjusting ring with the position indicator on the shock absorber. Use the special wrench and the extension bar included in the owner's tool kit to make the adjustment.



- 1. Spring preload adjusting ring
- 2. Position indicator
- 3. Extension bar
- 4. Special wrench

Spring preload setting: Minimum (soft):

1 Stan

Standard:


4

Maximum (hard):

9

Rebound damping force

To increase the rebound damping force and thereby harden the rebound damping, turn the adjusting screw in direction (a). To decrease the rebound damping force and thereby soften the rebound damping, turn the adjusting screw in direction (b).



1. Rebound damping force adjusting screw

Rebound damping setting:

Minimum (soft):

20 click(s) in direction (b)* Standard:

16 click(s) in direction (b)* Maximum (hard):


3 click(s) in direction (b)*

* With the adjusting screw fully turned in direction (a)

Compression damping force

Compression damping force (for fast compression damping)

To increase the compression damping force and thereby harden the compression damping, turn the adjusting bolt in direction (a). To decrease the compression damping force and thereby soften the compression damping, turn the adjusting bolt in direction (b).



1. Compression damping force adjusting bolt (for fast compression damping)

Compression damping setting (for fast compression damping):

Minimum (soft):

4 turn(s) in direction (b)* Standard:


3 turn(s) in direction (b)* Maximum (hard):

0 turn(s) in direction (b)*

* With the adjusting bolt fully turned in direction (a)

Compression damping force (for slow compression damping)

To increase the compression damping force and thereby harden the compression damping, turn the adjusting bolt in direction (a). To decrease the compression damping force and thereby soften the compression damping, turn the adjusting bolt in direction (b).



 Compression damping force adjusting bolt (for slow compression damping)

Compression damping setting (for slow compression damping):

Minimum (soft):

20 click(s) in direction (b)* Standard:

16 click(s) in direction (b)* Maximum (hard):

1 click(s) in direction (b)*

* With the adjusting bolt fully turned in direction (a)

TIP.

To obtain a precise adjustment, it is advisable to check the actual total number of clicks or turns of each damping force adjusting mechanism. This adjustment


range may not exactly match the specifications listed due to small differences in production.

WARNING

This shock absorber assembly contains highly pressurized nitrogen gas. Read and understand the following information before handling the shock absorber assembly.

- Do not tamper with or attempt to open the cylinder assembly.
- Do not subject the shock absorber assembly to an open flame or other high heat source.
 This may cause the unit to explode due to excessive gas pressure.
- Do not deform or damage the cylinder in any way. Cylinder damage will result in poor damping performance.
- Do not dispose of a damaged or worn-out shock absorber assembly yourself. Take the shock absorber assembly to a Yamaha dealer for any service.


Luggage strap holders



EAU38961

- 1. Luggage strap holder
- 2. Hook

EWA10221



1. Luggage strap holder

There are six luggage strap holders, four on the bottom of the passenger seat and one on each passenger footrest. To use the luggage strap holders

on the passenger seat, remove the passenger seat, unhook the straps from the hooks, and then install the seat with the straps hanging out from under the passenger seat. (See page 3-20.)

EXUP system

This model is equipped with Yamaha's EXUP (EXhaust Ultimate Power valve) system. This system boosts engine power by means of a valve that regulates the inner diameter of the exhaust pipe. The EXUP system valve is constantly adjusted in accordance with the engine speed by a computer-controlled servomotor.

NOTICE

ECA15610

The EXUP system has been set and extensively tested at the Yamaha factory. Changing these settings without sufficient technical knowledge may result in poor performance of or damage to the engine.

EAU41941

Sidestand

The sidestand is located on the left side of the frame. Raise the sidestand or lower it with your foot while holding the vehicle upright.

TIP

The built-in sidestand switch is part of the ignition circuit cut-off system, which cuts the ignition in certain situations. (See page 3-29 for an explanation of the ignition circuit cut-off system.)

EWA10241

EAU15304

WARNING

The vehicle must not be ridden with the sidestand down, or if the sidestand cannot be properly moved up (or does not stay up), otherwise the sidestand could contact the ground and distract the operator, resulting in a possible loss of control. Yamaha's ignition circuit cut-off system has been designed to assist the operator in fulfilling the responsibility of raising the sidestand before starting off. Therefore, check


this system regularly and have a Yamaha dealer repair it if it does not function properly. EAU44892

Ignition circuit cut-off system

The ignition circuit cut-off system (comprising the sidestand switch, clutch switch and neutral switch) has the following functions.

- It prevents starting when the transmission is in gear and the sidestand is up, but the clutch lever is not pulled.
- It prevents starting when the transmission is in gear and the clutch lever is pulled, but the sidestand is still down.
- It cuts the running engine when the transmission is in gear and the sidestand is moved down.

Periodically check the operation of the ignition circuit cut-off system according to the following procedure.



FOR YOUR SAFETY - PRE-OPERATION CHECKS

EAU15596

Inspect your vehicle each time you use it to make sure the vehicle is in safe operating condition. Always follow the inspection and maintenance procedures and schedules described in the Owner's Manual.

EWA11151

WARNING

Failure to inspect or maintain the vehicle properly increases the possibility of an accident or equipment damage. Do not operate the vehicle if you find any problem. If a problem cannot be corrected by the procedures provided in this manual, have the vehicle inspected by a Yamaha dealer.

Before using this vehicle, check the following points:

ITEM	CHECKS	PAGE
Fuel	Check fuel level in fuel tank. Refuel if necessary. Check fuel line for leakage. Check fuel tank breather/overflow hose for obstructions, cracks or damage, and check hose connection.	3-18, 3-19
Engine oil	 Check oil level in engine. If necessary, add recommended oil to specified level. Check vehicle for oil leakage. 	6-13
Coolant	Check coolant level in reservoir. If necessary, add recommended coolant to specified level. Check cooling system for leakage.	6-16
Front brake	 Check operation. If soft or spongy, have Yamaha dealer bleed hydraulic system. Check brake pads for wear. Replace if necessary. Check fluid level in reservoir. If necessary, add recommended brake fluid to specified level. Check hydraulic system for leakage. 	6-25, 6-25

FOR YOUR SAFETY – PRE-OPERATION CHECKS

ITEM	CHECKS	PAGE
Rear brake	Check operation. If soft or spongy, have Yamaha dealer bleed hydraulic system. Check brake pads for wear. Replace if necessary. Check fluid level in reservoir. If necessary, add recommended brake fluid to specified level. Check hydraulic system for leakage.	6-25, 6-25
Clutch	 Check operation. Lubricate cable if necessary. Check lever free play. Adjust if necessary. 	6-23
Throttle grip	Make sure that operation is smooth. Check throttle grip free play. If necessary, have Yamaha dealer adjust throttle grip free play and lubricate cable and grip housing.	6-19, 6-29
Control cables	• Make sure that operation is smooth. • Lubricate if necessary.	
Drive chain	Check chain slack. Adjust if necessary. Check chain condition. Lubricate if necessary.	6-27, 6-28
Wheels and tires	Check for damage. Check tire condition and tread depth. Check air pressure. Correct if necessary.	6-20, 6-22
Brake and shift pedals	Make sure that operation is smooth. Lubricate pedal pivoting points if necessary.	6-30
Brake and clutch levers	Make sure that operation is smooth. Lubricate lever pivoting points if necessary.	6-30
Sidestand	Make sure that operation is smooth. Lubricate pivot if necessary.	6-31

1

FOR YOUR SAFETY - PRE-OPERATION CHECKS

ITEM	CHECKS	PAGE
Chassis fasteners	Make sure that all nuts, bolts and screws are properly tightened. Tighten if necessary.	_
Instruments, lights, signals and switches		
Sidestand switch	Check operation of ignition circuit cut-off system. If system is not working correctly, have Yamaha dealer check vehicle.	3-28

EAU33015

OPERATION AND IMPORTANT RIDING POINTS

EAU15951

EAU46632

Read the Owner's Manual carefully to become familiar with all controls. If there is a control or function you do not understand, ask your Yamaha dealer.

WA10271

WARNING

Failure to familiarize yourself with the controls can lead to loss of control, which could cause an accident or injury. TIP

This model is equipped with:

- a lean angle sensor to stop the engine in case of a turnover. In this case, the multi-function display indicates error code 30, but this is not a malfunction. Turn the key to "OFF" and then to "ON" to clear the error code. Failing to do so will prevent the engine from starting even though the engine will crank when pushing the start switch.
- an engine auto-stop system. The engine stops automatically if left idling for 20 minutes. In this case, the multi-function display indicates error code 70, but this is not a malfunction. Push the start switch to clear the error code and to restart the engine.

Starting the engine

In order for the ignition circuit cut-off system to enable starting, one of the following conditions must be met:

- The transmission is in the neutral position.
- The transmission is in gear with the clutch lever pulled and the sidestand up.
 - See page 3-29 for more information.
- Turn the key to "ON" and make sure that the engine stop switch is set to "\(\cap\)".

The following warning lights and indicator lights should come on for a few seconds, then go off.

- Oil level warning light
- Fuel level warning light
- Coolant temperature warning light
- Shift timing indicator light
- Engine trouble warning light
- Immobilizer system indicator light

OPERATION AND IMPORTANT RIDING POINTS

ECA11833

NOTICE

If a warning or indicator light does not come on initially when the key is turned to "ON", or if a warning or indicator light remains on, see page 3-4 for the corresponding warning and indicator light circuit check.

- Shift the transmission into the neutral position. The neutral indicator light should come on. If not, ask a Yamaha dealer to check the electrical circuit.
- 3. Start the engine by pushing the start switch.


If the engine fails to start, release the start switch, wait a few seconds, and then try again. Each starting attempt should be as short as possible to preserve the battery. Do not crank the engine more than 10 seconds on any one attempt.

ECA11042

NOTICE

For maximum engine life, never accelerate hard when the engine is cold!

Shifting



- 1. Shift pedal
- 2. Neutral position

Shifting gears lets you control the amount of engine power available for starting off, accelerating, climbing hills, etc.

The gear positions are shown in the illustration.

TIP

To shift the transmission into the neutral position, press the shift pedal down repeatedly until it reaches the end of its travel, and then slightly raise it.

NOTICE

EAU16671

- Even with the transmission in the neutral position, do not coast for long periods of time with the engine off, and do not tow the motorcycle for long distances. The transmission is properly lubricated only when the engine is running. Inadequate lubrication may damage the transmission.
- Always use the clutch while changing gears to avoid damaging the engine, transmission, and drive train, which are not designed to withstand shock of forced shifting.

ECA10260

ECA10310

OPERATION AND IMPORTANT RIDING POINTS

EAU16841

EAU16810

Tips for reducing fuel consumption

Fuel consumption depends largely on your riding style. Consider the following tips to reduce fuel consumption:

- Shift up swiftly, and avoid high engine speeds during acceleration.
- Do not rev the engine while shifting down, and avoid high engine speeds with no load on the engine.
- Turn the engine off instead of letting it idle for an extended length of time (e.g., in traffic jams, at traffic lights or at railroad crossings).

Engine break-in

There is never a more important period in the life of your engine than the period between 0 and 1600 km (1000 mi). For this reason, you should read the following material carefully.

Since the engine is brand new, do not put an excessive load on it for the first 1600 km (1000 mi). The various parts in the engine wear and polish themselves to the correct operating clearances. During this period, prolonged full-throttle operation or any condition that might result in engine overheating must be avoided.

EAU17083

NOTICE

1600 km (1000 mi) and beyond

The vehicle can now be operated normally.

- Veen the engin
- Keep the engine speed out of the tachometer red zone.
- If any engine trouble should occur during the engine break-in period, immediately have a Yamaha dealer check the vehicle.

TIP.

During and after the engine break-in period, the exhaust heat may cause discoloration of the exhaust pipe, but this is normal.

0-1000 km (0-600 mi)

Avoid prolonged operation above 8300 r/min. *NOTICE:* After 1000 km (600 mi) of operation, the engine oil must be changed and the oil filter cartridge or element replaced. [ECATOSO2]

1000-1600 km (600-1000 mi)

Avoid prolonged operation above 9900 r/min.

OPERATION AND IMPORTANT RIDING POINTS

Parking

When parking, stop the engine, and then remove the key from the main switch.

EWA10311

EAU17213

WARNING

- Since the engine and exhaust system can become very hot, park in a place where pedestrians or children are not likely to touch them and be burned.
- Do not park on a slope or on soft ground, otherwise the vehicle may overturn, increasing the risk of a fuel leak and fire.
- Do not park near grass or other flammable materials which might catch fire.

EAU17302

PERIODIC MAINTENANCE AND ADJUSTMENT

EAU17243

WARNING

Turn off the engine when performing maintenance unless otherwise specified.

- A running engine has moving parts that can catch on body parts or clothing and electrical parts that can cause shocks or fires.
- Running the engine while servicing can lead to eve injury, burns, fire, or carbon monoxide poisoning - possibly leading to death. See page 1-1 for more information about carbon monoxide.

EWA10321

WARNING

be shortened.

the following pages.

Failure to properly maintain the vehicle or performing maintenance activities incorrectly may increase your risk of injury or death during service or while using the vehicle. If vou are not familiar with vehicle service, have a Yamaha dealer perform service.

Periodic inspection, adjustment, and lu-

brication will keep your vehicle in the

safest and most efficient condition pos-

sible. Safety is an obligation of the vehi-

cle owner/operator. The most important

points of vehicle inspection, adjust-

ment, and lubrication are explained on

The intervals given in the periodic

maintenance charts should be simply

considered as a general guide under

normal riding conditions. However, de-

pending on the weather, terrain, geo-

graphical location, and individual use,

the maintenance intervals may need to

EWA15121

EWA15460

Emission controls not only function to ensure cleaner air, but are also vital to proper engine operation and maximum performance. In the following periodic maintenance charts, the services related to emissions control are grouped separately. These services require specialized data, knowledge, and equipment. Maintenance, replacement, or repair of the emission control devices and systems may be performed by any repair establishment or individual that is certified (if applicable). Yamaha dealers are trained and equipped to perform these particular services.


WARNING

Brake discs, calipers, drums, and linings can become very hot during use. To avoid possible burns, let brake components cool before touching them.

6-1

Owner's tool kit

EAU17542



1. Owner's tool kit

The owner's tool kit is located under the passenger seat. (See page 3-20.)

The service information included in this manual and the tools provided in the owner's tool kit are intended to assist you in the performance of preventive maintenance and minor repairs. However, additional tools such as a torque wrench may be necessary to perform certain maintenance work correctly.

TIP _____

If you do not have the tools or experience required for a particular job, have a Yamaha dealer perform it for you.

EAU46861

TIF

- The annual checks must be performed every year, except if a kilometer-based maintenance, or for the UK, a mileage-based maintenance, is performed instead.
- From 50000 km (30000 mi), repeat the maintenance intervals starting from 10000 km (6000 mi).
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

Periodic maintenance chart for the emission control system

EAU46910

		ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING					ANNUAL
N	Э.			1000 km (600 mi)	10000 km (6000 mi)	20000 km (12000 mi)	30000 km (18000 mi)	40000 km (24000 mi)	CHECK
1	*	Fuel line	Check fuel hoses for cracks or damage.		V	V	V	√	V
2	*	Spark plugs	Check condition.Clean and regap.		V		V		
			Replace.			√		√	
3	*	Valves	Check valve clearance. Adjust.	Every 40000 km (24000 mi)					
4	*	Fuel injection system	Adjust synchronization.		V	V	V	√	$\sqrt{}$
5	*	Muffler and exhaust pipe	Check the screw clamp(s) for looseness.	√	V	√	V	√	
6	*	Air induction system	Check the air cut-off valve, reed valve, and hose for damage. Replace any damaged parts if necessary.		V	V	V	7	√

EAU1770C

General maintenance and lubrication chart

				ODOMETER READING					ANNUAL
N	Ο.	ITEM	CHECK OR MAINTENANCE JOB	1000 km (600 mi)	10000 km (6000 mi)	20000 km (12000 mi)	30000 km (18000 mi)	40000 km (24000 mi)	CHECK
1	*	Air filter element	Replace.					√	
2		Clutch	Check operation. Adjust.	√	√	√	V	V	
3	*	Front brake	Check operation, fluid level and vehicle for fluid leakage.	V	√	√	V	V	V
			Replace brake pads.			Whenever wo	orn to the limit		
4	*	Rear brake	Check operation, fluid level and vehicle for fluid leakage.	V	√	√	V	V	V
		Replace brake pads. Whenever worn to the limit							
5	*	Brake hoses	Check for cracks or damage.		√	\checkmark	$\sqrt{}$	√	\checkmark
ľ		brake noses	• Replace.	Every 4 years					
6	*	Wheels	Check runout and for damage.		√	√	√	√	
7	*	Tires	 Check tread depth and for damage. Replace if necessary. Check air pressure. Correct if necessary. 		1	1	V	7	√
8	*	Wheel bearings	Check bearing for looseness or damage.		√	√	V	√	
9	*	Swingarm	Check operation and for excessive play.		√	√	V	V	
9		Swingarm	Lubricate with lithium-soap-based grease.			Every 50000 l	km (30000 mi))	

		ITEM	CHECK OR MAINTENANCE JOB	ODOMETER READING					ANNUAL	
NO.	-			1000 km (600 mi)	10000 km (6000 mi)	20000 km (12000 mi)	30000 km (18000 mi)	40000 km (24000 mi)	CHECK	
10		Drive chain	Check chain slack, alignment and condition. Adjust and lubricate chain with a special O-ring chain lubricant thoroughly.	Every 800 km (500 mi) and after washing the motorcycle, riding in the riding in wet areas						
11	*	Steering bearings	Check bearing play and steering for roughness.	V	V	√	V	V		
		Steering bearings	Lubricate with lithium-soap-based grease.	Every 20000 km (12000 mi)						
12	*	Chassis fasteners	Make sure that all nuts, bolts and screws are properly tightened.		V	V	√	V	√	
13		Brake lever pivot shaft	Lubricate with silicone grease.		V	V	V	V	\checkmark	
14		Brake pedal pivot shaft	Lubricate with lithium-soap-based grease.		√	√	$\sqrt{}$	V	\checkmark	
15		Clutch lever pivot shaft	Lubricate with lithium-soap-based grease.		√	V	√	V	√	
16		Shift pedal pivot shaft	Lubricate with lithium-soap-based grease.		√	V	V	√	V	
17		Sidestand	Check operation. Lubricate with lithium-soap-based grease.		V	V	√	√	√	
18	*	Sidestand switch	Check operation.	√	√	√	√	√	√	
19	*	Front fork	Check operation and for oil leakage.		V	√	V	V		
20	*	Shock absorber as- sembly	Check operation and shock absorber for oil leakage.		√	V	√	√		

				ODOMETER READING					
NO.		ITEM	CHECK OR MAINTENANCE JOB	1000 km (600 mi)	10000 km (6000 mi)	20000 km (12000 mi)	30000 km (18000 mi)	40000 km (24000 mi)	ANNUAL CHECK
21	*	Rear suspension re- lay arm and con- necting arm pivoting points	Check operation.		√	V	√	V	
22		Engine oil	Change.Check oil level and vehicle for oil leakage.	V	V	V	V	V	V
23		Engine oil filter car- tridge	• Replace.	\checkmark		V		V	
24	*	* Cooling system	Check coolant level and vehicle for coolant leakage.		V	√	√	√	√
			Change.	Every 3 years					
25	*	Front and rear brake switches	Check operation.	V	V	V	V	V	√
26		Moving parts and cables	• Lubricate.		V	V	√	V	√
27	*	Throttle grip	 Check operation. Check throttle grip free play, and adjust if necessary. Lubricate cable and grip housing. 		√	V	√	V	√
28	*	Lights, signals and switches	Check operation. Adjust headlight beam.	V	V	V	V	V	V

EAU18680


TIP

- Air filter
 - This model's air filter is equipped with a disposable oil-coated paper element, which must not be cleaned with compressed air to avoid damaging it.
 - The air filter element needs to be replaced more frequently when riding in unusually wet or dusty areas.
- Hydraulic brake service
 - Regularly check and, if necessary, correct the brake fluid level.
 - Every two years replace the internal components of the brake master cylinders and calipers, and change the brake fluid.
 - Replace the brake hoses every four years and if cracked or damaged.


EAU18712

Removing and installing cowlings and panels


The cowlings and panels shown need to be removed to perform some of the maintenance jobs described in this chapter. Refer to this section each time a cowling or panel needs to be removed and installed.



1. Cowling A



- 1. Cowling B
- 2. Cowling C




- 1. Panel A
- 2. Panel B

Cowlings A and B


To remove a cowling

1. Remove the bolts, quick fasteners, and quick fastener screw.

EAU44932




- 1. Cowling A
- 2. Bolt
- 3. Quick fastener




1. Quick fastener







- 1. Quick fastener
- 2. Quick fastener screw




- 1. Cowling B
- 2. Bolt
- 3. Quick fastener




1. Quick fastener




- 1. Quick fastener
- 2. Quick fastener screw
 - Remove the projection on cowling A from the hole in cowling B as shown.



- 1. Cowling A
- 2. Cowling B
- Remove the forward-most projection from the slot, slide the cowling forward, and then remove the remaining projections from the slots as shown.
- 4. Disconnect the turn signal light lead coupler.



- 1. Cowling A
- 2. Turn signal light lead coupler




- 1. Cowling B
- 2. Turn signal light lead coupler


To install a cowling

1. Connect the turn signal light lead coupler.

2. Fit the projections into the slots, slide the cowling rearward, and then fit the forward-most projection into the slot.




- 1. Cowling A
- 2. Turn signal light lead coupler



- 1. Cowling B
- 2. Turn signal light lead coupler

3. Fit the projection on cowling A into the hole in cowling B as shown.




- 2. Cowling B
 - 4. Install the bolts, quick fasteners, and quick fastener screw.

Cowling C


EAU39092

To remove the cowling

- 1. Remove cowling B and panel B. (See page 6-8.)
- 2. Unfasten the wire harness by pressing on the projection to open the plastic fastener.




- 1. Plastic fastener
- 2. Projection
- 3. Wire harness
 - 3. Remove the bolts and the quick fastener, and then pull the cowling off as shown.



- 1. Cowling C
- 2. Bolt
- 3. Quick fastener

To install the cowling

1. Fit the slot in cowling C over the projection on the front cowling.




- 1. Cowling C
- 2. Slot
- 3. Front cowling
- 4. Projection
 - 2. Install the bolts and the quick fastener.
 - 3. Place the wire harness in the original position, and then close the plastic fastener.
 - 4. Install the cowling and the panel.

EAU39061

Panels A and B

To remove one of the panels


Remove the bolts, and then pull the panel off as shown.



- 2. Bolt

To install the panel

Place the panel in the original position, and then install the bolts.




Checking the spark plugs

The spark plugs are important engine components, which should be checked periodically, preferably by a Yamaha dealer. Since heat and deposits will cause any spark plug to slowly erode, they should be removed and checked in accordance with the periodic maintenance and lubrication chart. In addition, the condition of the spark plugs can reveal the condition of the engine.

The porcelain insulator around the center electrode of each spark plug should be a medium-to-light tan (the ideal color when the vehicle is ridden normally), and all spark plugs installed in the engine should have the same color. If any spark plug shows a distinctly different color, the engine could be operating improperly. Do not attempt to diagnose such problems yourself. Instead, have a Yamaha dealer check the vehicle. If a spark plug shows signs of electrode

erosion and excessive carbon or other deposits, it should be replaced.

Specified spark plug: NGK/CR10EK Before installing a spark plug, the spark plug gap should be measured with a wire thickness gauge and, if necessary, adjusted to specification.



1. Spark plug gap

Spark plug gap:

0.6-0.7 mm (0.024-0.028 in)

Clean the surface of the spark plug gasket and its mating surface, and then wipe off any grime from the spark plug threads.

Tightening torque:

Spark plug: 13 Nm (1.3 m·kgf, 9.4 ft·lbf) TIP

If a torque wrench is not available when installing a spark plug, a good estimate of the correct torque is 1/4–1/2 turn past finger tight. However, the spark plug should be tightened to the specified torque as soon as possible.

ECA10840

NOTICE

Do not use any tools to remove or install the spark plug cap, otherwise the ignition coil coupler may get damaged. The spark plug cap may be difficult to remove because the rubber seal on the end of the cap fits tightly. To remove the spark plug cap, simply twist it back and forth while pulling it out; to install it, twist it back and forth while pushing it in.

Engine oil and oil filter cartridge

FAU3899A


The engine oil level should be checked before each ride. In addition, the oil must be changed and the oil filter cartridge replaced at the intervals specified in the periodic maintenance and lubrication chart.

To check the engine oil level


- Place the vehicle on a level surface and hold it in an upright position. A slight tilt to the side can result in a false reading.
- Start the engine, warm it up for several minutes, and then turn it off.
- Wait a few minutes until the oil settles.
- Remove the engine oil dipstick and wipe it clean, insert it back into the hole (without screwing it in), and then remove it again to check the oil level.

TIP

The engine oil should be between the minimum and maximum level marks.



- 1. Engine oil dipstick
- 2. Maximum level mark
- 3. Minimum level mark
 - If the engine oil is at or below the minimum level mark, remove the engine oil filler cap, and then add sufficient oil of the recommended type to raise it to the correct level.




1. Engine oil filler cap

Insert and tighten the engine oil dipstick, and then install and tighten the oil filler cap.

To change the engine oil (with or without oil filter cartridge replacement)

- Place the vehicle on a level surface.
- 2. Remove cowling A. (See page 6-8.)
- Start the engine, warm it up for several minutes, and then turn it off.
- 4. Place an oil pan under the engine to collect the used oil.
- Remove the engine oil filler cap, the engine oil drain bolt and its gasket to drain the oil from the crankcase.




- 1. Engine oil drain bolt
- 2. Gasket


TIP _____

Skip steps 6–12 if the oil filter cartridge is not being replaced.

- Remove the shift arm by removing the bolt and pulling it off the shift shaft.
- 7. Remove the fuel tank breather/overflow hoses from the guides.



- 1. Bolt
- 2. Shift arm
- 3. Engine oil filter cartridge
- 4. Guide
- 5. Fuel tank breather/overflow hose
 - 8. Remove the oil filter cartridge with an oil filter wrench.




1. Oil filter wrench

TIP

An oil filter wrench is available at a Yamaha dealer.

Apply a thin coat of clean engine oil to the O-ring of the new oil filter cartridge.




1. O-ring

TIP.

Make sure that the O-ring is properly seated.

 Install the new oil filter cartridge with an oil filter wrench, and then tighten it to the specified torque with a torque wrench.



1. Torque wrench


Tightening torque:

Oil filter cartridge: 17 Nm (1.7 m·kgf, 12 ft·lbf)

- Install the fuel tank breather/overflow hoses into the guides, then place them in their original position.
- 12. Install the shift arm by aligning the match mark on the shift arm with the match mark on the shift shaft and installing the bolt, then tightening it to the specified torque. NOTICE: Be sure to align the match marks to ensure proper shifting. If the match marks are not aligned, the shift arm will

not move correctly and you may not be able to shift up or down.

[ECA15342]



- 1. Bolt
- 2. Shift shaft
- 3. Match marks
- 4. Shift arm

Tightening torque:

Shift arm bolt:

10 Nm (1.0 m·kgf, 7.2 ft·lbf)

13. Install the engine oil drain bolt and its new gasket, and then tighten the bolt to the specified torque.

Tightening torque:

Engine oil drain bolt: 43 Nm (4.3 m·kgf, 31 ft·lbf) Refill with the specified amount of the recommended engine oil, and then install and tighten the oil filler cap.

Recommended engine oil:

See page 8-1.

Oil quantity:

Without oil filter cartridge replacement:

2.40 L (2.54 US qt, 2.11 Imp.qt) With oil filter cartridge replacement: 2.60 L (2.75 US qt, 2.29 Imp.qt)

TIP_

Be sure to wipe off spilled oil on any parts after the engine and exhaust system have cooled down.

ECA11620

NOTICE

 In order to prevent clutch slippage (since the engine oil also lubricates the clutch), do not mix any chemical additives. Do not use oils with a diesel specification of "CD" or oils of a higher quality than specified. In

addition, do not use oils labeled "ENERGY CONSERVING II" or higher.

- Make sure that no foreign material enters the crankcase.
- 15. Start the engine, and then let it idle for several minutes while checking it for oil leakage. If oil is leaking, immediately turn the engine off and check for the cause.

TIP _____

After the engine is started, the engine oil level warning light should go off if the oil level is sufficient.

FCA10401

NOTICE

If the oil level warning light flickers or remains on even if the oil level is correct, immediately turn the engine off and have a Yamaha dealer check the vehicle.

- Turn the engine off, and then check the oil level and correct it if necessary.
- 17. Install the cowling.

Coolant

The coolant level should be checked before each ride. In addition, the coolant must be changed at the intervals specified in the periodic maintenance and lubrication chart.

EAU39087

FAU20070

To check the coolant level


 Place the vehicle on a level surface and hold it in an upright position.

TIP

- The coolant level must be checked on a cold engine since the level varies with engine temperature.
- Make sure that the vehicle is positioned straight up when checking the coolant level. A slight tilt to the side can result in a false reading.
- Check the coolant level in the coolant reservoir.

TIP _____

The coolant should be between the minimum and maximum level marks.




- 1. Coolant reservoir
- 2. Maximum level mark
- 3. Minimum level mark
 - If the coolant is at or below the minimum level mark, remove panel B to access the coolant reservoir. (See page 6-8.)
- 4. Remove the coolant reservoir cap, add coolant to the maximum level mark, and then install the reservoir cap. WARNING! Remove only the coolant reservoir cap. Never attempt to remove the radiator cap when the engine is hot.

 [EWA15161] NOTICE: If coolant is not available, use distilled water or soft tap water instead. Do not use hard water or salt water since it is harmful to the engine.

FAU39004

If water has been used instead of coolant, replace it with coolant as soon as possible, otherwise the cooling system will not be protected against frost and corrosion. If water has been added to the coolant, have a Yamaha dealer check the antifreeze content of the coolant as soon as possible, otherwise the effectiveness of the coolant will be reduced. [ECA10472]




1. Coolant reservoir cap

Coolant reservoir capacity (up to the maximum level mark): 0.25 L (0.26 US qt, 0.22 Imp.qt)

5. Install the panel.


To change the coolant

- Place the vehicle on a level surface and let the engine cool if necessary.
- 2. Remove cowlings B and C. (See page 6-8.)
- 3. Place a container under the engine to collect the used coolant.
- 4. Remove the radiator cap. WARNING! Never attempt to remove the radiator cap when the engine is hot. [EWA10381]




- 1. Radiator cap
 - Remove the coolant drain bolt and its gasket to drain the cooling system.

Move the hose clamp in the direction shown, and then disconnect the radiator hose to drain the radiator.



- 1. Coolant drain bolt
- 2. Gasket
- 3. Radiator hose
- 4. Hose clamp
 - 7. Remove the coolant reservoir by removing the bolts.
- 8. Remove the coolant reservoir cap, and then turn the coolant reservoir upside down to empty it.



- 1. Coolant reservoir cap
- 2. Coolant reservoir
- 3. Bolt
- After the coolant is completely drained, thoroughly flush the cooling system with clean tap water.
- Install the coolant reservoir by installing the bolts.
- 11. Connect the radiator hose, and then move the hose clamp back to its original position.
- 12. Install the coolant drain bolt and its new gasket, and then tighten the bolt to the specified torque.

Tightening torque:

Coolant drain bolt:

10 Nm (1.0 m·kgf, 7.2 ft·lbf)

- Pour the recommended coolant into the reservoir to the maximum level mark, and then install the coolant reservoir cap.
- 14. Pour the recommended coolant into the radiator until it is full.

Antifreeze/water mixture ratio:

1:1

Recommended antifreeze:

High-quality ethylene glycol antifreeze containing corrosion inhibitors for aluminum engines

Coolant quantity:

Radiator capacity (including all routes):

2.30 L (2.43 US qt, 2.02 Imp.qt) Coolant reservoir capacity (up to the maximum level mark):

0.25 L (0.26 US qt, 0.22 Imp.qt)

- Install the radiator cap, start the engine, let it idle for several minutes, and then turn it off.
- Remove the radiator cap to check the coolant level in the radiator. If necessary, add sufficient coolant until it reaches the top of the radiator, and then install the radiator cap.

- 17. Start the engine, and then check the vehicle for coolant leakage. If coolant is leaking, have a Yamaha dealer check the cooling system.
- 18. Install the cowlings.

Air filter element

The air filter element must be replaced at the intervals specified in the periodic maintenance and lubrication chart. Have a Yamaha dealer replace the air filter element.

EAU36764


Checking the engine idling speed

Check the engine idling speed and, if necessary, have it corrected by a Yamaha dealer.

Engine idling speed: 1250–1350 r/min

EAU44734

Checking the throttle grip free play



1. Throttle grip free play

The throttle grip free play should measure 3.0–5.0 mm (0.12–0.20 in) at the inner edge of the throttle grip. Periodically check the throttle grip free play and, if necessary, have a Yamaha dealer adjust it.

Valve clearance

The valve clearance changes with use, resulting in improper air-fuel mixture and/or engine noise. To prevent this from occurring, the valve clearance must be adjusted by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.

EAU21401

Tires

To maximize the performance, durability, and safe operation of your motorcycle, note the following points regarding the specified tires.

Tire air pressure

The tire air pressure should be checked and, if necessary, adjusted before each ride.

EWA10503

WARNING

Operation of this vehicle with improper tire pressure may cause severe injury or death from loss of control.

- The tire air pressure must be checked and adjusted on cold tires (i.e., when the temperature of the tires equals the ambient temperature).
- The tire air pressure must be adjusted in accordance with the riding speed and with the total weight of rider, passenger, cargo, and accessories approved for this model.

Tire air pressure (measured on cold tires):

0-90 kg (0-198 lb):

Front:

250 kPa (2.50 kgf/cm², 36 psi)

Rear:

290 kPa (2.90 kgf/cm², 42 psi)

90-186 kg (198-410 lb):

Front:

250 kPa (2.50 kgf/cm², 36 psi)

Rear:

290 kPa (2.90 kgf/cm², 42 psi)

High-speed riding:

Front:

250 kPa (2.50 kgf/cm², 36 psi)

Rear:

290 kPa (2.90 kgf/cm², 42 psi)

Maximum load*:

186 kg (410 lb)


* Total weight of rider, passenger, cargo and accessories

EWA10511

WARNING

Never overload your vehicle. Operation of an overloaded vehicle could cause an accident.

Tire inspection



- 1. Tire sidewall
- 2. Tire tread depth

The tires must be checked before each ride. If the center tread depth reaches the specified limit, if the tire has a nail or glass fragments in it, or if the sidewall is cracked, have a Yamaha dealer replace the tire immediately.

Minimum tire tread depth (front and rear):

1.6 mm (0.06 in)


TIP

The tire tread depth limits may differ from country to country. Always comply with the local regulations.

WARNING

- Have a Yamaha dealer replace excessively worn tires. Besides being illegal, operating the vehicle with excessively worn tires decreases riding stability and can lead to loss of control.
- The replacement of all wheel and brake-related parts, including the tires, should be left to a Yamaha dealer, who has the necessary professional knowledge and experience to do so.
- Ride at moderate speeds after changing a tire since the tire surface must first be "broken in" for it to develop its optimal characteristics.

EWA10471 Tire information



- 1. Tire air valve
- Tire air valve core
- 3. Tire air valve cap with seal

This motorcycle is equipped with cast wheels and tubeless tires with valves.

WARNING

- The front and rear tires should be of the same make and design, otherwise the handling characteristics of the motorcycle may be different, which could lead to an accident
- Always make sure that the valve caps are securely installed to prevent air pressure leakage.

 Use only the tire valves and valve cores listed below to avoid tire deflation during a high-speed ride.

After extensive tests, only the tires listed below have been approved for this model by Yamaha Motor Co., Ltd.

Front tire:

Size:

120/70 ZR17M/C (58W) Manufacturer/model: BRIDGESTONE/BT016F F DUNLOP/Qualifier PT M

Rear tire:

Size:

180/55 ZR17M/C (73W)
Manufacturer/model:
BRIDGESTONE/BT016R F
DUNLOP/Qualifier PT M

FRONT and REAR:

Tire air valve: TR412

Valve core:

#9100 (original)

WARNING

This motorcycle is fitted with superhigh-speed tires. Note the following points in order to make the most efficient use of these tires.

- Use only the specified replacement tires. Other tires may run the danger of bursting at super high speeds.
- Brand-new tires can have a relatively poor grip on certain road surfaces until they have been "broken in". Therefore, it is advisable before doing any highspeed riding to ride conservatively for approximately 100 km (60 mi) after installing a new tire.
- The tires must be warmed up before a high-speed run.
- Always adjust the tire air pressure according to the operating conditions.

EWA10600


Cast wheels

To maximize the performance, durability, and safe operation of your vehicle, note the following points regarding the specified wheels.

EAU21961

- The wheel rims should be checked for cracks, bends or warpage before each ride. If any damage is found, have a Yamaha dealer replace the wheel. Do not attempt even the smallest repair to the wheel. A deformed or cracked wheel must be replaced.
- The wheel should be balanced whenever either the tire or wheel has been changed or replaced. An unbalanced wheel can result in poor performance, adverse handling characteristics, and a shortened tire life.

Adjusting the clutch lever free play



- 1. Clutch lever free play adjusting bolt
- 2. Clutch lever free play


The clutch lever free play should measure 10.0–15.0 mm (0.39–0.59 in) as shown. Periodically check the clutch lever free play and, if necessary, adjust it as follows.

To increase the clutch lever free play, turn the clutch lever free play adjusting bolt at the clutch lever in direction (a). To decrease the clutch lever free play, turn the adjusting bolt in direction (b).

TIP

If the specified clutch lever free play cannot be obtained as described above, proceed as follows.


- 1. Fully turn the adjusting bolt at the clutch lever in direction (a) to loosen the clutch cable.
- 2. Loosen the locknut at the crankcase.
- 3. To increase the clutch lever free play, turn the clutch lever free play adjusting nut in direction (a). To decrease the clutch lever free play, turn the adjusting nut in direction (b).



- 1. Locknut
- 2. Clutch lever free play adjusting nut (crank-case)

4. Tighten the locknut.

Checking the brake lever free play



1. No brake lever free play

There should be no free play at the brake lever end. If there is free play, have a Yamaha dealer inspect the brake system.


EWA14211

WARNING

A soft or spongy feeling in the brake lever can indicate the presence of air in the hydraulic system. If there is air in the hydraulic system, have a Yamaha dealer bleed the system before operating the vehicle. Air in the hydraulic system will diminish the braking performance, which may result in loss of control and an accident.

Brake light switches





- 1. Rear brake light switch
- 2. Rear brake light switch adjusting nut

The brake light, which is activated by the brake pedal and brake lever, should come on just before braking takes effect. If necessary, adjust the rear brake light switch as follows, but the front brake light switch should be adjusted by a Yamaha dealer.

Turn the rear brake light switch adjusting nut while holding the rear brake light switch in place. To make the brake light come on earlier, turn the adjusting nut in direction (a). To make the brake light come on later, turn the adjusting nut in direction (b).

FAU46291


EAU2239

EAU36890

Checking the front and rear brake pads

The front and rear brake pads must be checked for wear at the intervals specified in the periodic maintenance and lubrication chart.

Front brake pads




1. Brake pad wear indicator

Each front brake pad is provided with wear indicators, which allows you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the position of the wear indicators while applying the brake. If a brake pad has worn to

the point that a wear indicator almost touches the brake disc, have a Yamaha dealer replace the brake pads as a set.

Rear brake pads



1. Brake pad wear indicator groove


Each rear brake pad is provided with wear indicator grooves, which allow you to check the brake pad wear without having to disassemble the brake. To check the brake pad wear, check the wear indicator grooves. If a brake pad has worn to the point that a wear indicator groove almost appears, have a Yamaha dealer replace the brake pads as a set.

Checking the brake fluid level



1. Minimum level mark

Rear brake



1. Minimum level mark

Insufficient brake fluid may allow air to enter the brake system, possibly causing it to become ineffective.

Before riding, check that the brake fluid is above the minimum level mark and replenish if necessary. A low brake fluid level may indicate worn brake pads and/or brake system leakage. If the brake fluid level is low, be sure to check the brake pads for wear and the brake system for leakage.

Observe these precautions:

- When checking the fluid level, make sure that the top of the brake fluid reservoir is level.
- Use only the recommended quality brake fluid, otherwise the rubber seals may deteriorate, causing leakage and poor braking performance.

Recommended brake fluid:

 Refill with the same type of brake fluid. Mixing fluids may result in a harmful chemical reaction and lead to poor braking performance.

- Be careful that water does not enter the brake fluid reservoir when refilling. Water will significantly lower the boiling point of the fluid and may result in vapor lock.
- Brake fluid may deteriorate painted surfaces or plastic parts. Always clean up spilled fluid immediately.
- As the brake pads wear, it is normal for the brake fluid level to gradually go down. However, if the brake fluid level goes down suddenly, have a Yamaha dealer check the cause.

EAU22731

Changing the brake fluid

Have a Yamaha dealer change the brake fluid at the intervals specified in the TIP after the periodic maintenance and lubrication chart. In addition, have the oil seals of the master cylinders and calipers as well as the brake hoses replaced at the intervals listed below or whenever they are damaged or leaking.

- Oil seals: Replace every two years.
- Brake hoses: Replace every four years.

Drive chain slack

The drive chain slack should be checked before each ride and adjusted if necessary.

EAU22773

EAU22760

To check the drive chain slack

 Place the motorcycle on the sidestand.


TIP ___

When checking and adjusting the drive chain slack, there should be no weight on the motorcycle.

- 2. Shift the transmission into the neutral position.
- Move the rear wheel by pushing the motorcycle to locate the tightest portion of the drive chain, and then measure the drive chain slack as shown.

Drive chain slack:


30.0-45.0 mm (1.18-1.77 in)



- 1. Drive chain slack
 - 4. If the drive chain slack is incorrect, adjust it as follows.

To adjust the drive chain slack

1. Loosen the axle nut and the locknut on each side of the swingarm.




- 1. Drive chain slack adjusting bolt
- 2. Locknut
- 3. Alignment marks
- 4. Axle nut
- 5. Drive chain puller
- 2. To tighten the drive chain, turn the drive chain slack adjusting bolt on each side of the swingarm in direction (a). To loosen the drive chain, turn the adjusting bolt on each side of the swingarm in direction (b), and then push the rear wheel forward. NOTICE: Improper drive chain slack will overload the engine as well as other vital parts of the motorcycle and can lead to chain slippage or breakage.

To prevent this from occurring, keep the drive chain slack within the specified limits. [ECA10571]

TIP ____

Using the alignment marks on each drive chain puller, make sure that both chain pullers are in the same position for proper wheel alignment. Use the end of the swingarm as the reference point for the alignment marks.



- 1. Drive chain slack adjusting bolt
- 2. Locknut
- 3. Tighten the axle nut to the specified torque.

Tightening torque:

Axle nut:

110 Nm (11 m·kgf, 80 ft·lbf)

4. Tighten the adjusting bolts in direction (a) to their specified torque.

Tightening torque:

Drive chain slack adjusting bolt: 2.0 Nm (0.20 m·kgf, 1.4 ft·lbf)

Tighten the locknuts to their specified torque.

Tightening torque:

Locknut:

16 Nm (1.6 m·kgf, 12 ft·lbf)

Cleaning and lubricating the

The drive chain must be cleaned and lubricated at the intervals specified in the periodic maintenance and lubrication chart, otherwise it will quickly wear out, especially when riding in dusty or wet areas. Service the drive chain as follows.

ECA10583

FAU23025

NOTICE

drive chain

The drive chain must be lubricated after washing the motorcycle, riding in the rain or riding in wet areas.

- Clean the drive chain with kerosene and a small soft brush.
 NOTICE: To prevent damaging the O-rings, do not clean the drive chain with steam cleaners, high-pressure washers or inappropriate solvents. [ECA11121]
- 2. Wipe the drive chain dry.
- Thoroughly lubricate the drive chain with a special O-ring chain lubricant. NOTICE: Do not use engine oil or any other lubricants for the drive chain, as they

may contain substances that could damage the O-rings.

[ECA11111]

EAU23093

Checking and lubricating the cables

The operation of all control cables and the condition of the cables should be checked before each ride, and the cables and cable ends should be lubricated if necessary. If a cable is damaged or does not move smoothly, have a Yamaha dealer check or replace it. WARNING! Damage to the outer housing of cables may result in internal rusting and cause interference with cable movement. Replace damaged cables as soon as possible to prevent unsafe conditions.

[EWA10711]

Recommended lubricant:

Yamaha Chain and Cable Lube or engine oil

EAU23113 Checking and lubricating the throttle grip and cable


The operation of the throttle grip should be checked before each ride. In addition, the cable should be lubricated by a Yamaha dealer at the intervals specified in the periodic maintenance chart. The throttle cable is equipped with a rubber boot. Make sure that the boot is securely installed. Even though the boot is installed correctly, it does not completely protect the cable from water entry. Therefore, use care not to pour water directly onto the boot or cable when washing the vehicle. If the cable or boot becomes dirty, wipe clean with a moist cloth.

Checking and lubricating the brake and shift pedals


Recommended lubricant: Lithium-soap-based grease

Checking and lubricating the brake and clutch levers

Brake lever




Clutch lever




The operation of the brake and clutch levers should be checked before each ride, and the lever pivots should be lubricated if necessary.

Brake pedal



Shift pedal



The operation of the brake and shift pedals should be checked before each ride, and the pedal pivots should be lubricated if necessary.

FAUM1651

PERIODIC MAINTENANCE AND ADJUSTMENT


EWA10731

Recommended lubricants:

Brake lever: Silicone grease Clutch lever:

Lithium-soap-based grease

Checking and lubricating the sidestand




The operation of the sidestand should be checked before each ride, and the sidestand pivot and metal-to-metal contact surfaces should be lubricated if necessary.

WARNING

If the sidestand does not move up and down smoothly, have a Yamaha dealer check or repair it. Otherwise, the sidestand could contact the ground and distract the operator, resulting in a possible loss of control.

Recommended lubricant: Lithium-soap-based grease

EAU23202 Lubricating the swingarm pivots



The swingarm pivots must be lubricated by a Yamaha dealer at the intervals specified in the periodic maintenance and lubrication chart.

Recommended lubricant:

Lithium-soap-based grease

EAU23272

Checking the front fork


The condition and operation of the front fork must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

To check the condition

Check the inner tubes for scratches, damage and excessive oil leakage.

To check the operation

- Place the vehicle on a level surface and hold it in an upright position. WARNING! To avoid injury, securely support the vehicle so there is no danger of it falling over. [EWA10751]
- While applying the front brake, push down hard on the handlebars several times to check if the front fork compresses and rebounds smoothly.



NOTICE

If any damage is found or the front fork does not operate smoothly, have a Yamaha dealer check or repair it.


ECA10590

Checking the steering


Worn or loose steering bearings may cause danger. Therefore, the operation of the steering must be checked as follows at the intervals specified in the periodic maintenance and lubrication chart.

FAU23283

- Place a stand under the engine to raise the front wheel off the ground. (See page 6-39 for more information.) WARNING! To avoid injury, securely support the vehicle so there is no danger of it falling over. [EWA10751]
- Hold the lower ends of the front fork legs and try to move them forward and backward. If any free play can be felt, have a Yamaha dealer check or repair the steering.




Checking the wheel bearings



The front and rear wheel bearings must be checked at the intervals specified in the periodic maintenance and lubrication chart. If there is play in the wheel hub or if the wheel does not turn smoothly, have a Yamaha dealer check the wheel bearings.

Battery



- 1. Battery
- 2. Negative battery lead (black)
- 3. Positive battery lead (red)

The battery is located under the rider seat. (See page 3-20.)

This model is equipped with a VRLA (Valve Regulated Lead Acid) battery. There is no need to check the electrolyte or to add distilled water. However, the battery lead connections need to be checked and, if necessary, tightened.

EWA10760

WARNING

 Electrolyte is poisonous and dangerous since it contains sulfuric acid, which causes severe burns. Avoid any contact with

EAU50210

skin, eyes or clothing and always shield your eyes when working near batteries. In case of contact, administer the following FIRST AID.

- EXTERNAL: Flush with plenty of water.
- INTERNAL: Drink large quantities of water or milk and immediately call a physician.
- EYES: Flush with water for 15 minutes and seek prompt medical attention.
- Batteries produce explosive hydrogen gas. Therefore, keep sparks, flames, cigarettes, etc., away from the battery and provide sufficient ventilation when charging it in an enclosed space.
- KEEP THIS AND ALL BATTER-IES OUT OF THE REACH OF CHILDREN.

To charge the battery

Have a Yamaha dealer charge the battery as soon as possible if it seems to have discharged. Keep in mind that the

battery tends to discharge more quickly if the vehicle is equipped with optional electrical accessories.

ECA16521

NOTICE

To charge a VRLA (Valve Regulated Lead Acid) battery, a special (constant-voltage) battery charger is required. Using a conventional battery charger will damage the battery.

To store the battery

 If the vehicle will not be used for more than one month, remove the battery, fully charge it, and then place it in a cool, dry place. NOTICE: When removing the battery, be sure the key is turned to "OFF", then disconnect the negative lead before disconnecting the positive lead.

[ECA16302]

- If the battery will be stored for more than two months, check it at least once a month and fully charge it if necessary.
- Fully charge the battery before installation. NOTICE: When installing the battery, be sure the key

is turned to "OFF", then connect the positive lead before connecting the negative lead.

[ECA16840]

4. After installation, make sure that the battery leads are properly connected to the battery terminals.


ECA16530

NOTICE

Always keep the battery charged. Storing a discharged battery can cause permanent battery damage. EAU23705


Replacing the fuses

The main fuse, the fuel injection system fuse, and fuse box 1 are located under the rider seat. (See page 3-20.)



- 1. Main fuse
- 2. Fuel injection system spare fuse
- 3. Fuel injection system fuse
- 4. Fuse box 1
- Backup fuse (for clock and immobilizer system)
- 6. Electronic throttle valve fuse
- 7. Spare fuse

Fuse box 2 is located under panel A. (See page 6-8.)



- 1. Fuse box 2
- 2. Left radiator fan fuse
- 3. Right radiator fan fuse
- 4. Signaling system fuse
- 5. Ignition fuse
- 6. Taillight fuse
- 7. Headlight fuse
- 8. Spare fuse

If a fuse is blown, replace it as follows.

- 1. Turn the key to "OFF" and turn off the electrical circuit in question.
- 2. Remove the blown fuse, and then install a new fuse of the specified amperage. WARNING! Do not use a fuse of a higher amperage rating than recommended to avoid causing extensive damage to the electrical system and possibly a fire. [EWA15131]

Specified fuses:

Main fuse:

50.0 A

Fuel injection system fuse:

15.0 A

Electronic throttle valve fuse:

7.5 A

Backup fuse:

7.5 A

Radiator fan fuse:

15.0 A × 2

Ignition fuse:

15.0 A

Signaling system fuse:

10.0 A

Taillight fuse:

7.5 A

Headlight fuse:

15.0 A

- 3. Turn the key to "ON" and turn on the electrical circuit in question to check if the device operates.
- 4. If the fuse immediately blows again, have a Yamaha dealer check the electrical system.

Replacing a headlight bulb

This model is equipped with quartz bulb headlights. If a headlight bulb burns out, replace it as follows.

ECA10650

EAU39012

NOTICE

Take care not to damage the following parts:


Headlight bulb

Do not touch the glass part of the headlight bulb to keep it free from oil, otherwise the transparency of the glass, the luminosity of the bulb, and the bulb life will be adversely affected. Thoroughly clean off any dirt and fingerprints on the headlight bulb using a cloth moistened with alcohol or thinner.


Headlight lens

Do not affix any type of tinted film or stickers to the headlight lens.


Do not use a headlight bulb of a wattage higher than specified.




- 1. Do not touch the glass part of the bulb.
 - 1. Remove the headlight bulb cover by turning it counterclockwise.



- 1. Headlight bulb cover
- 2. Disconnect the headlight coupler.



- 1. Headlight coupler
 - Unhook the headlight bulb holder, and then remove the burnt-out bulb.



- 1. Headlight bulb holder
 - 4. Place a new headlight bulb into position, and then secure it with the bulb holder.
 - 5. Connect the headlight coupler.

- 6. Install the headlight bulb cover by turning it clockwise.
- 7. Have a Yamaha dealer adjust the headlight beam if necessary.


Tail/brake light

This model is equipped with an LED-type tail/brake light.

If the tail/brake light does not come on, have a Yamaha dealer check it.

Replacing a turn signal light bulb


1. Remove the turn signal light lens by removing the screw.



1. Screw

EAU24181


2. Remove the burnt-out bulb by pushing it in and turning it counter-clockwise.



- 1. Turn signal light bulb
- 3. Insert a new bulb into the socket, push it in, and then turn it clockwise until it stops.
- 4. Install the lens by installing the screw. *NOTICE:* Do not overtighten the screw, otherwise the lens may break. [ECA11191]

Replacing the license plate light bulb

1. Remove the license plate light unit by removing the screws.




- Screw
 - 2. Remove the license plate light bulb socket (together with the bulb) by pulling it out.



- 1. License plate light bulb
- 2. License plate light unit
 - Remove the burnt-out bulb by pulling it out.
 - 4. Insert a new bulb into the socket.
- 5. Install the socket (together with the bulb) by pushing it in.
- 6. Install the license plate light unit by installing the screws.

Auxiliary light





1. Auxiliary light

This model is equipped with an LEDtype auxiliary light.

If the auxiliary light does not come on, have a Yamaha dealer check it.

Supporting the motorcycle

Since this model is not equipped with a centerstand, follow these precautions when removing the front and rear wheel or performing other maintenance requiring the motorcycle to stand upright. Check that the motorcycle is in a stable and level position before starting any maintenance. A strong wooden box can be placed under the engine for added stability.

To service the front wheel

- Stabilize the rear of the motorcycle by using a motorcycle stand or, if an additional motorcycle stand is not available, by placing a jack under the frame in front of the rear wheel.
- 2. Raise the front wheel off the ground by using a motorcycle stand.

To service the rear wheel

Raise the rear wheel off the ground by using a motorcycle stand or, if a motorcycle stand is not available, by placing a jack either under each side of the frame in front of the rear wheel or under each side of the swingarm.

Front wheel

EAU24360


To remove the front wheel

EAU33923 EWA10821

M WARNING


To avoid injury, securely support the vehicle so there is no danger of it falling over.

1. Loosen the front wheel axle pinch bolts, the axle bolt, and then the brake caliper bolts.




- 1. Front wheel axle pinch bolt
 - 2. Lift the front wheel off the ground according to the procedure on page 6-39.

- Remove the brake hose holder on each side by removing the bolt and nut.
- 4. Remove the brake caliper on each side by removing the bolts.



- 1. Brake hose holder
- 2. Bolt and nut
- 3. Brake caliper bolt
- 4. Brake caliper
- 5. Axle bolt
- 5. Remove the axle bolt, push the wheel axle out from the left side, and then remove the wheel. NOTICE: Do not apply the brake after the brake calipers have been removed, otherwise the brake pads will be forced shut.

[ECA11051]



1. Wheel axle

To install the front wheel

- 1. Lift the wheel up between the fork legs.
- 2. Insert the wheel axle.
- Install the axle bolt, and then lower the front wheel so that it is on the ground, and then put the sidestand down.
- 4. Install the brake calipers by installing the bolts, and then tightening them to the specified torque.

TIP_

Make sure that there is enough space between the brake pads before installing the brake calipers onto the brake discs.

Tightening torque:

Brake caliper bolt: 35 Nm (3.5 m·kgf, 25 ft·lbf)

- 5. Install the brake hose holders by installing the bolts and nuts.
- 6. Tighten the axle bolt to the specified torque.

TIP __

EAU33934


While tightening the axle bolt, hold the wheel axle with a 19-mm hexagon wrench to keep it from turning.

Tightening torque:

Axle bolt:

91 Nm (9.1 m·kgf, 66 ft·lbf)

Tighten wheel axle pinch bolt B, then pinch bolt A to the specified torque.



- 1. Front wheel axle pinch bolt A
- 2. Front wheel axle pinch bolt B
- 3. Front wheel axle pinch bolt C
- 4. Front wheel axle pinch bolt D
 - 8. Retighten pinch bolt B to the specified torque.

Tightening torque:

Wheel axle pinch bolt: 21 Nm (2.1 m·kgf, 15 ft·lbf)

- 9. Tap the outer side of the right fork leg with a rubber mallet to align it with the end of the wheel axle.
- Tighten wheel axle pinch bolt D, then pinch bolt C to the specified torque.
- 11. Retighten pinch bolt D to the specified torque.

Tightening torque:

Wheel axle pinch bolt: 21 Nm (2.1 m·kgf, 15 ft·lbf)

 While applying the front brake, push down hard on the handlebar several times to check for proper fork operation.

Rear wheel

EAU25080


To remove the rear wheel

EAU44953 EWA10821

WARNING


To avoid injury, securely support the vehicle so there is no danger of it falling over.

1. Loosen the axle nut.




- 1. Axle nut
- 2. Brake caliper
- 3. Brake caliper bracket
- Lift the rear wheel off the ground according to the procedure on page 6-39.
- 3. Remove the axle nut.

- 4. Fully loosen the locknut on each side of the swingarm.
- Turn the drive chain slack adjusting bolts in direction (a) to loosen the drive chain enough so it can be removed from the rear sprocket, and then push the wheel forward.




- 1. Drive chain slack adjusting bolt
- 2. Locknut
 - 6. Remove the drive chain from the rear sprocket.



TIP

- If the drive chain is difficult to remove, remove the wheel axle first, and then lift the wheel upward enough to remove the drive chain from the rear sprocket.
- The drive chain cannot be disassembled.
- 7. While supporting the brake caliper bracket, pull the wheel axle out, and then remove the wheel. NOTICE: Do not apply the brake after the wheel has been removed together with the brake disc, otherwise the brake pads will be forced shut. [ECA11071]



1. Wheel axle


To install the rear wheel

EAU39172

 Install the wheel and the brake caliper bracket by inserting the wheel axle from the left-hand side.

TIP.

- Be sure to insert the retainer on the brake caliper bracket into the slot in the swingarm.
- Make sure that there is enough space between the brake pads before installing the wheel.




- 1. Retainer
- 2. Slot
 - 2. Install the drive chain onto the rear sprocket.
 - 3. Install the axle nut, and then lower the rear wheel so that it is on the ground, and then put the sidestand down.
 - 4. Adjust the drive chain slack. (See page 6-27.)
 - 5. Tighten the axle nut to the specified torque.

Tightening torque:

Axle nut:

110 Nm (11 m·kgf, 80 ft·lbf)

6. Tighten the adjusting bolts in direction (b) to their specified torque.



Tightening torque:

Drive chain slack adjusting bolt: 2.0 Nm (0.20 m·kgf, 1.4 ft·lbf)

7. Tighten the locknuts to their specified torque.

Tightening torque:

Locknut:

16 Nm (1.6 m·kgf, 12 ft·lbf)

Troubleshooting

Although Yamaha motorcycles receive a thorough inspection before shipment from the factory, trouble may occur during operation. Any problem in the fuel, compression, or ignition systems, for example, can cause poor starting and loss of power.

The following troubleshooting charts represent quick and easy procedures for checking these vital systems yourself. However, should your motorcycle require any repair, take it to a Yamaha dealer, whose skilled technicians have the necessary tools, experience, and know-how to service the motorcycle properly.

Use only genuine Yamaha replacement parts. Imitation parts may look like Yamaha parts, but they are often inferior, have a shorter service life and can lead to expensive repair bills.

EWA15141

EAU25871

WARNING


When checking the fuel system, do not smoke, and make sure there are no open flames or sparks in the area, including pilot lights from water

heaters or furnaces. Gasoline or gasoline vapors can ignite or explode, causing severe injury or property damage.

Troubleshooting charts

EAU42501

Starting problems or poor engine performance




Engine overheating

WARNING

 Do not remove the radiator cap when the engine and radiator are hot. Scalding hot fluid and steam may be blown out under pressure, which could cause serious injury. Be sure to wait until the engine has cooled.

Place a thick rag, like a towel, over the radiator cap, and then slowly rotate the cap counterclockwise to the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the cap while turning it counterclockwise, and then remove the cap.



TIP

If coolant is not available, tap water can be temporarily used instead, provided that it is changed to the recommended coolant as soon as possible.

MOTORCYCLE CARE AND STORAGE

EAU26023

Matte color caution

EAU37833

ECA15192

NOTICE

Some models are equipped with matte colored finished parts. Be sure to consult a Yamaha dealer for advice on what products to use before cleaning the vehicle. Using a brush, harsh chemical products or cleaning compounds when cleaning these parts will scratch or damage their surface. Wax also should not be applied to any matte colored finished parts.

Care

While the open design of a motorcycle reveals the attractiveness of the technology, it also makes it more vulnerable. Rust and corrosion can develop even if high-quality components are used. A rusty exhaust pipe may go unnoticed on a car, however, it detracts from the overall appearance of a motorcycle. Frequent and proper care does not only comply with the terms of the warranty, but it will also keep your motorcycle looking good, extend its life and optimize its performance.

Before cleaning

- 1. Cover the muffler outlet with a plastic bag after the engine has cooled down.
- 2. Make sure that all caps and covers as well as all electrical couplers and connectors, including the spark plug caps, are tightly installed.
- Remove extremely stubborn dirt, like oil burnt onto the crankcase, with a degreasing agent and a brush, but never apply such prod-

ucts onto seals, gaskets, sprockets, the drive chain and wheel axles. Always rinse the dirt and de-

greaser off with water.

Cleaning

ECA11142

NOTICE

- Avoid using strong acidic wheel cleaners, especially on spoked wheels. If such products are used on hard-to-remove dirt, do not leave the cleaner on the affected area any longer than instructed. Also, thoroughly rinse the area off with water, immediately dry it, and then apply a corrosion protection spray.
- Improper cleaning can damage plastic parts (such as cowlings, panels, windshields, headlight lenses, meter lenses, etc.) and the mufflers. Use only a soft, clean cloth or sponge with water to clean plastic. However, if the plastic parts cannot be thoroughly cleaned with water, diluted mild detergent with water may be used. Be sure to rinse

MOTORCYCLE CARE AND STORAGE

- off any detergent residue using plenty of water, as it is harmful to plastic parts.
- Do not use any harsh chemical products on plastic parts or the muffler. Be sure to avoid using cloths or sponges which have been in contact with strong or abrasive cleaning products, solvent or thinner, fuel (gasoline), rust removers or inhibitors, brake fluid, antifreeze or electrolyte.
- Do not use high-pressure washers or steam-jet cleaners since they cause water seepage and deterioration in the following areas: seals (of wheel and swingarm bearings, fork and brakes), storage compartments, electric components (couplers, connectors, instruments, switches and lights), breather hoses and vents.
- For motorcycles equipped with a windshield: Do not use strong cleaners or hard sponges as they will cause dulling or scratching. Some cleaning com-

pounds for plastic may leave scratches on the windshield. Test the product on a small hidden part of the windshield to make sure that it does not leave any marks. If the windshield is scratched, use a quality plastic polishing compound after washing.

After normal use

Remove dirt with warm water, a mild detergent, and a soft, clean sponge, and then rinse thoroughly with clean water. Use a toothbrush or bottlebrush for hard-to-reach areas. Stubborn dirt and insects will come off more easily if the area is covered with a wet cloth for a few minutes before cleaning.

After riding in the rain, near the sea or on salt-sprayed roads

Since sea salt or salt sprayed on roads during winter are extremely corrosive in combination with water, carry out the following steps after each ride in the rain, near the sea or on salt-sprayed roads.

TIP_

Salt sprayed on roads in the winter may remain well into spring.

- Clean the motorcycle with cold water and a mild detergent, after the engine has cooled down.
 NOTICE: Do not use warm water since it increases the corrosive action of the salt. [ECA10791]
- After drying the motorcycle, apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces (except the titanium muffler) to prevent corrosion.

Cleaning the titanium muffler

This model is equipped with a titanium muffler, which requires the following special care.

 Use only a soft, clean cloth or sponge with mild detergent and water to clean the titanium muffler. However, if the muffler cannot be thoroughly cleaned with mild detergent, alkaline products and a soft brush may be used.

ECA10800

MOTORCYCLE CARE AND STORAGE

- Never use compounds or other special treatments to clean the titanium muffler, as they will remove the finish on the outer surface of the muffler.
- Even the smallest amounts of oil, such as from oily towels or fingerprints, will leave stains on the titanium muffler, which can be removed with a mild detergent.
- Note that the thermally induced discoloring of the portion of the exhaust pipe leading into the titanium muffler is normal and cannot be removed.

After cleaning

- 1. Dry the motorcycle with a chamois or an absorbing cloth.
- 2. Immediately dry the drive chain and lubricate it to prevent it from rusting.
- 3. Use a chrome polish to shine chrome, aluminum and stainless-steel parts.

- To prevent corrosion, it is recommended to apply a corrosion protection spray on all metal, including chrome- and nickel-plated, surfaces.
- 5. Use spray oil as a universal cleaner to remove any remaining dirt.
- 6. Touch up minor paint damage caused by stones, etc.
- 7. Wax all painted surfaces.
- 8. Let the motorcycle dry completely before storing or covering it.

EWA11131

WARNING

Contaminants on the brakes or tires can cause loss of control.

- Make sure that there is no oil or wax on the brakes or tires.
- If necessary, clean the brake discs and brake linings with a regular brake disc cleaner or acetone, and wash the tires with warm water and a mild detergent. Before riding at higher speeds, test the motorcycle's braking performance and cornering behavior.

NOTICE

 Apply spray oil and wax sparingly and make sure to wipe off any excess.

- Never apply oil or wax to any rubber and plastic parts, but treat them with a suitable care product.
- Avoid using abrasive polishing compounds as they will wear away the paint.

TIP

- Consult a Yamaha dealer for advice on what products to use.
- Washing, rainy weather or humid climates can cause the headlight lens to fog. Turning the headlight on for a short period of time will help remove the moisture from the lens.

MOTORCYCLE CARE AND STORAGE

Storage

EAU26182

Short-term

Always store your motorcycle in a cool, dry place and, if necessary, protect it against dust with a porous cover. Be sure the engine and the exhaust system are cool before covering the motorcycle.

ECA10810

NOTICE

- Storing the motorcycle in a poorly ventilated room or covering it with a tarp, while it is still wet, will allow water and humidity to seep in and cause rust.
- To prevent corrosion, avoid damp cellars, stables (because of the presence of ammonia) and areas where strong chemicals are stored.

Long-term

Before storing your motorcycle for several months:

1. Follow all the instructions in the "Care" section of this chapter.

- 2. Fill up the fuel tank and add fuel stabilizer (if available) to prevent the fuel tank from rusting and the fuel from deteriorating.
- 3. Perform the following steps to protect the cylinders, piston rings, etc. from corrosion
 - a. Remove the spark plug caps and spark plugs.
 - b. Pour a teaspoonful of engine oil into each spark plug bore.
 - c. Install the spark plug caps onto the spark plugs, and then place the spark plugs on the cylinder head so that the electrodes are grounded. (This will limit sparking during the next step.)
 - d. Turn the engine over several times with the starter. (This will coat the cylinder walls with oil.) WARNING! To prevent damage or injury from sparking. make sure to ground the spark plug electrodes while turning the engine over.

[EWA10951]

- e. Remove the spark plug caps from the spark plugs, and then install the spark plugs and the spark plug caps.
- 4. Lubricate all control cables and the pivoting points of all levers and pedals as well as of the sidestand/centerstand.
- 5. Check and, if necessary, correct the tire air pressure, and then lift the motorcycle so that both of its wheels are off the ground. Alternatively, turn the wheels a little every month in order to prevent the tires from becoming degraded in one spot.
- 6. Cover the muffler outlet with a plastic bag to prevent moisture from entering it.
- 7. Remove the battery and fully charge it. Store it in a cool, dry place and charge it once a month. Do not store the battery in an excessively cold or warm place [less than 0 °C (30 °F) or more than 30 °C (90 °F)]. For more information on storing the battery, see page 6-33.

MOTORCYCLE CARE AND STORAGE

TIP _				
Make	any	necessary	repairs	before
storing	j the i	motorcycle.	·	

SPECIFICATIONS

Dimensions:

Overall length:

2040 mm (80.3 in)

Overall width:

705 mm (27.8 in)

Overall height:

1100 mm (43.3 in)

Seat height:

850 mm (33.5 in)

Wheelbase:

1380 mm (54.3 in)

Ground clearance:

130 mm (5.12 in)

Minimum turning radius:

3600 mm (141.7 in)

Weight:

With oil and fuel: 189 kg (417 lb)

Engine:

Engine type:

Liquid cooled 4-stroke, DOHC

Cylinder arrangement:

Forward-inclined parallel 4-cylinder

Displacement:

599 cm³ Bore × stroke:

 $67.0 \times 42.5 \text{ mm} (2.64 \times 1.67 \text{ in})$

Compression ratio:

13.10:1

Starting system:

Electric starter

Lubrication system:

Wet sump


Engine oil:

Recommended brand:

YAMALUBE

Type:

SAE 10W-40, 10W-50, 15W-40, 20W-40 or 20W-50



Recommended engine oil grade:

API service SG type or higher, JASO standard MA

Engine oil quantity:

Without oil filter cartridge replacement:

2.40 L (2.54 US qt, 2.11 Imp.qt)

With oil filter cartridge replacement:

2.60 L (2.75 US qt, 2.29 Imp.qt)

Cooling system:

Coolant reservoir capacity (up to the maximum level mark):

0.25 L (0.26 US qt, 0.22 Imp.qt)

Radiator capacity (including all routes): 2.30 L (2.43 US gt, 2.02 Imp.gt)

Air filter:

Air filter element:

Oil-coated paper element

Fuel:

Recommended fuel:

Premium unleaded gasoline only

Fuel tank capacity:

17.3 L (4.57 US gal, 3.81 Imp.gal)

Fuel reserve amount:

3.5 L (0.92 US gal, 0.77 Imp.gal)

Fuel injection:

Throttle body:

ID mark:

13S1 00

Spark plug(s):

Manufacturer/model:

NGK/CR10EK

Spark plug gap:

0.6-0.7 mm (0.024-0.028 in)

Clutch:

Clutch type:

Wet, multiple-disc

Transmission:

Primary reduction system:

Spur gear

Primary reduction ratio:

85/41 (2.073)

Secondary reduction system:

Chain drive

Secondary reduction ratio:

45/16 (2.813)

Transmission type:

Constant mesh 6-speed

Operation:

Left foot operation

SPECIFICATIONS

Gear ratio:	Manufacturer/model:	Rear wheel:
1st:	BRIDGESTONE/BT016R F	Wheel type:
31/12 (2.583)	Manufacturer/model:	Cast wheel
2nd:	DUNLOP/Qualifier PT M	Rim size:
32/16 (2.000)	Loading:	17M/C x MT5.50
3rd:	Maximum load:	Front brake:
30/18 (1.667)	186 kg (410 lb)	Type:
4th:	(Total weight of rider, passenger, cargo and	Dual disc brake
26/18 (1.444)	accessories)	Operation:
5th:	Tire air pressure (measured on cold	Right hand operation
27/21 (1.286)	tires):	Recommended fluid:
6th:	Loading condition:	DOT 4
23/20 (1.150)	0–90 kg (0–198 lb)	Rear brake:
Chassis:	Front:	Type:
Frame type:	250 kPa (2.50 kgf/cm², 36 psi)	Single disc brake
Diamond	Rear:	Operation:
Caster angle:	290 kPa (2.90 kgf/cm², 42 psi)	Right foot operation
24.00 °	Loading condition:	Recommended fluid:
Trail:	90–186 kg (198–410 lb)	DOT 4
97.0 mm (3.82 in)	Front:	Front suspension:
Front tire:	250 kPa (2.50 kgf/cm², 36 psi)	Type:
Type:	Rear:	Telescopic fork
Tubeless	290 kPa (2.90 kgf/cm ² , 42 psi)	Spring/shock absorber type:
Size:	High-speed riding:	Coil spring/oil damper
120/70 ZR17M/C (58W)	Front:	Wheel travel:
Manufacturer/model:	250 kPa (2.50 kgf/cm², 36 psi)	115.0 mm (4.53 in)
BRIDGESTONE/BT016F F	Rear:	Rear suspension:
Manufacturer/model:	290 kPa (2.90 kgf/cm², 42 psi)	Type:
DUNLOP/Qualifier PT M	Front wheel:	Swingarm (link suspension)
Rear tire:	Wheel type:	Spring/shock absorber type:
Type:	Cast wheel	Coil spring/gas-oil damper
Tubeless	Rim size:	Wheel travel:
Size:	17M/C x MT3.50	120.0 mm (4.72 in)
180/55 ZR17M/C (73W)		

LED

SPECIFICATIONS


Electrical system:	Turn signal indicator light:
Ignition system:	LED
TCI	Fuel level warning light:
Charging system:	LED
AC magneto	Coolant temperature warning light
Battery:	LED
Model:	Engine trouble warning light:
YTZ10S	LED
Voltage, capacity:	Immobilizer system indicator light:
12 V, 8.6 Ah	LED
Headlight:	Shift timing indicator light:
Bulb type:	LED
Halogen bulb	Fuses:
Bulb voltage, wattage × quantity:	Main fuse:
Headlight:	50.0 A
12 V, 55 W × 2	Headlight fuse:
Tail/brake light:	15.0 A
LED	Taillight fuse:
Front turn signal light:	7.5 A
12 V, 10.0 W × 2	Signaling system fuse:
Rear turn signal light:	10.0 A
12 V, 10.0 W × 2	Ignition fuse:
Auxiliary light:	15.0 A
LED	Radiator fan fuse:
License plate light:	15.0 A × 2
12 V, 5.0 W × 1	Fuel injection system fuse:
Meter lighting:	15.0 A
LED	Backup fuse:
Neutral indicator light:	7.5 A
LED	Electronic throttle valve fuse:
High beam indicator light:	7.5 A
LED	
Oil level warning light:	

CONSUMER INFORMATION

Identification numbers

Record the vehicle identification number and model label information in the spaces provided below for assistance when ordering spare parts from a Yamaha dealer or for reference in case the vehicle is stolen.


VEHICLE IDENTIFICATION NUMBER:



MODEL LABEL INFORMATION:



Vehicle identification number



1. Vehicle identification number

The vehicle identification number is stamped into the steering head pipe. Record this number in the space provided.

TIP


EAU48611

The vehicle identification number is used to identify your motorcycle and may be used to register your motorcycle with the licensing authority in your area.

Model label

EAU26400

EAU26520



1. Model label

The model label is affixed to the frame under the passenger seat. (See page 3-20.) Record the information on this label in the space provided. This information will be needed when ordering spare parts from a Yamaha dealer.

INDEX

A	Engine stop switch 3-15	Model label9-1
Air filter element 6-19	Engine trouble warning light 3-7	Multi-function meter unit3-8
Anti-theft alarm (optional)3-14	EXUP system 3-28	N
Auxiliary light6-38	F	Neutral indicator light3-4
3	Front and rear brake pads, checking 6-25	0
Battery6-33	Front fork, adjusting 3-23	Oil level warning light3-4
Brake and clutch levers, checking and	Front fork, checking 6-32	P
lubricating 6-30	Fuel 3-18	Parking5-4
Brake and shift pedals, checking and	Fuel consumption, tips for reducing 5-3	Part locations2-1
lubricating 6-30	Fuel level warning light3-4	Pass switch3-14
Brake fluid, changing6-26	Fuel tank breather/overflow hose 3-19	R
Brake fluid level, checking 6-25	Fuel tank cap 3-17	Rear view mirrors3-22
Brake lever3-16	Fuses, replacing 6-34	S
Brake lever free play, checking6-24	Н	Safety information1-1
Brake light switches6-24	Handlebar switches 3-14	Seats
Brake pedal3-17	Hazard switch3-15	Shifting5-2
	Headlight bulb, replacing 6-35	Shift pedal3-16
Cables, checking and lubricating 6-29	Helmet holding cable 3-21	Shift timing indicator light3-7
Care7-1	High beam indicator light 3-4	Shock absorber assembly, adjusting3-25
Catalytic converters3-19	Horn switch 3-15	Sidestand3-28
Clutch lever3-15	I	Sidestand, checking and lubricating6-31
Clutch lever free play, adjusting 6-23	Identification numbers 9-1	Spark plugs, checking6-12
Coolant6-16	Ignition circuit cut-off system 3-29	Specifications8-1
Coolant temperature warning light 3-5	Immobilizer system 3-1	Starting the engine5-1
Cowlings and panels, removing and	Immobilizer system indicator light 3-7	Start switch3-15
installing6-8	Indicator lights and warning lights 3-4	Steering, checking6-32
	L	Storage7-4
Dimmer switch 3-14	License plate light bulb, replacing 6-38	Supporting the motorcycle6-39
Drive chain, cleaning and lubricating 6-28	Luggage strap holders3-27	Swingarm pivots, lubricating6-31
Drive chain slack6-27	M	T
≣	Main switch/steering lock 3-2	Tail/brake light6-37
Engine break-in5-3	Maintenance and lubrication, periodic 6-4	Throttle grip and cable, checking and
Engine idling speed, checking 6-19	Maintenance, emission control system 6-3	lubricating6-29
Engine oil and oil filter cartridge6-13	Matte color, caution 7-1	Throttle grip free play, checking6-19
-	•	3.12

INDEX

Tires	6-20
Tool kit	6-2
Troubleshooting	6-43
Troubleshooting charts	6-45
Turn signal indicator lights	
Turn signal light bulb, replacing	6-37
Turn signal switch	
V	
Valve clearance	6-20
Vehicle identification number	9-1
W	
Wheel bearings, checking	6-33
Wheel (front)	
Wheel (rear)	
Wheels	6-22

